
Circulating Fluid Temperature Controller Thermo-chiller


HRS Series Standard Type



Temperature stability $\pm 0.1^{\circ}C$ / Compact

A precision temperature control method which utilizes expansion valves and temperature sensors allowed for the realization of a product with a high temperature stability of $\pm 0.1^{\circ}$ C and a small-size tank.

Air-cooled HRS




Refrigeration circuit

- The compressor compresses the refrigerant gas and discharges high-temperature, high-pressure refrigerant gas.
- In the case of air-cooled refrigeration, the high-temperature, high-pressure refrigerant gas is cooled down by fan ventilation in the air-cooled condenser, where it is then liquefied. In the case of water-cooled refrigeration, the refrigerant gas is cooled by the facility water in the facility water circuit in the water-cooled condenser, where it is then liquefied.
- The liquefied high-pressure refrigerant gas expands and its temperature lowers when it passes through expansion valve A, where it vaporizes after receiving heat from the circulating fluid in the evaporator.
- The vaporized refrigerant gas is sucked into the compressor and compressed again.
- When heating the circulating fluid, the high-pressure, hightemperature refrigerant gas is bypassed into the evaporator by expansion valve B to heat the circulating fluid.



■ Water-cooled HRS□-W-□



Circulating fluid circuit


- After the circulating fluid discharged from the pump is heated or cooled by the user's equipment, it returns to the thermo-chiller.
- The circulating fluid is controlled to remain at a set temperature by the refrigeration circuit. It will then be discharged to the user's equipment side again by the thermo-chiller.
- Point Since the refrigeration circuit is controlled by the signals from 2 temperature sensors (for return and discharge), precise temperature control of the circulating fluid can be achieved. Therefore, there is no need for a tank with a large capacity to absorb the circulating fluid temperature difference, as high temperature stability can be achieved even with a small-size tank. This also contributes to space saving.

Facility water circuit


For water-cooled refrigeration HRS□-W-□

• The water-regulating valve opens and closes to keep the refrigerant gas pressure consistent. The facility water flow rate is controlled by the water-regulating valve.

Can be installed with both sides close to a wall




Reduced-height double condenser structure (HRS030/040/060)



A maximum reduction in the height of the product has been achieved while expanding the cooling capacity by providing overlapped air-cooled condensers.

SMC



HRS

HRS-R

HRS 100/150 HRS090

HRS200

HRSH090

HRSH

HRSE

HRR

HRL

HRZ

HRZD

HRW


HECR

HEC

HEB


HED

Technical Data



SMC

26



Timer for ON and OFF can be set in units of 0.5 h up to 99.5 h.

Ex.) Can be set to stop on Saturday and Sunday and restart on Monday morning

Ex. SE.02 "ON timer"



- Temperature and pressure units can be changed.
- Orange Temperature unit indicator MPa PS Pressure unit lights up. O REMOTE O BILN O ALARM 4 RUN/ Stop

SMC

- Automatic restart after stoppage due to power failure, etc., is possible without pressing the RUNY key, and remote operation is also possible.
- Anti-freezing operation function If the circulating fluid approaches its freezing point, for example, on a cold winter night, the pump operates automatically, and the heat generated by the pump warms the circulating fluid, preventing freezing.
- Key-lock function

Can be set in advance to protect the set values from being changed by pressing keys by mistake.

- Function to output a signal for completion of preparation Notifies by communication when the temperature reaches the pre-set temperature range
- Independent operation of the pump The pump can be operated independently while the chiller is powered off. This allows you to check for leakages in piping and to remove the air.

PV 🗄 🕴

0

Alarm code

Self-diagnosis function and check display

Display of 35 types of alarm codes For details, refer to page 50.

Operation is monitored at all times by the integrated sensor.

Should any error occur, the self-diagnosis result is displayed by the applicable alarm code (35 types).


This makes it easier to identify the cause of the alarm. Can be used before requesting service

Changeable alarm set values									
Setting item	Set value								
Circulating fluid discharge temperature rise	5 to 48°C								
Circulating fluid discharge temperature drop	1 to 39°C								
Circulating fluid discharge pressure rise	0.05 to 0.75 MPa*1								
Circulating fluid discharge pressure drop	0.05 to 0.18 MPa*1								

*1 Set values vary depending on the model.

Alarm codes can be used for the notification of upcoming recommended maintenance.

The codes notify you when it's time to check the pump and fan motor. Helpful for facility maintenance * A fan motor is not used in water-cooled refrigeration.



Check display

Flashing

Lights up

O REMOTE


O RUN

RUN/

STOP

The internal temperature, pressure, and operating time of the product are displayed.

Ex. AL01 "Low level in tank"




Displayed item Circulating fluid outlet temperature Circulating fluid return temperature Compressor gas temperature Circulating fluid outlet pressure Circulating fluid outlet pressure Compressor gas discharge pressure Compressor gas return pressure Accumulated operating time Accumulated operating time of pump Accumulated operating time of fan motor*1 Accumulated operating time of compressor *1 These are displayed only for air-cooled refrigeration.

Communication function


Serial communication (RS232C/RS485) and contact I/Os (2 inputs and 3 outputs) are equipped as standard. This allows for communication with the user's equipment and system construction, depending on the application. A 24 VDC output can be also provided and is available for use with flow switches (SMC's PF2W, etc.).

Ex. 1 Remote signal I/O through serial communication Remote operation is enabled (to start and stop operation)

Hemote operation is enabled (to start and stop operation) through serial communication.




The alarm and status generated in the product are assigned to 3 output signals based on their contents, which can then be output.



• Output setting example Output 1: Temperature rise Output 2: Pressure rise Output 3: Operation status (start, stop, etc.)

Ex. 2 Remote operation signal input

One of the contact inputs is used for remote operation and the other is used to monitor the flow of a flow switch. This is where their alarm outputs are taken in.



Power for flow switches (24 VDC) can be supplied by the thermo-chiller.

HRS

Application Examples

A.S.	Heat source	Automotive	Light electrical appliance	Food	Machinery	Medical	Semiconductor	Laser
Arc welding machines	Torch	•			•			
Resistance welding machines	Tip	•	•		•			
Laser welding machines	Oscillator	•	•		•		•	
Laser beam machines	Oscillator/ Power supply							•
Fiber lasers Oscillators Transmission cable connectors								•
Secondary battery manufacturing processes	Welded portion							•
3D metal printers Additive manufacturing								•
UV curing devices	Lamp	•	•	•		•		
X-ray instruments			•			•	•	
Electronic microscopes	Lens		•			•	•	
MRIs						•		
Laser markers	Oscillator	•	•	•		•	•	•
Ultrasonic wave inspection machines	Oscillator	•	•		•			•
Atomizing devices Crushing equipment	Blade			•				
Linear motors	Motor	•			•			
Packaging lines (food)	Dies/ Welded portions			•				

Application Examples

2-11	Heat source	Automotive	Light electrical appliance	Food	Machinery	Medical	Semiconductor	Laser	
Atomizing devices (food and cosmetics)	Sample/ Device			•	•				
Mold cooling	Mold	•	•	•		•			RH
Machining centers	Spindle				•				HHS-F
									HRS09
Injection molding					•				HRS 00/150
Temperature control of adhesive and paint materials	Paint material/ Welding materials	•	•	•					HRS200
Cooling of vacuum pumps	Pump	•					•		НВЗН090 НВЗ200 НВЗ НВЗ090 НВЗ-В
Shrink fit machines	Workpiece	•			•				HRSH
Gas cylinder cabinets							•		HRSE
Testers			•				•		НВВ
Concentrating equipment	Test liquid			•		•			НВГ
Reagent cooling equipment	Reagent			•		•	•		HRZ
	Cleaning								HRZD
Cleaning machines	solution		•				•		МЯН
Printing machines	Roller		•	•	•				HECR
Chamber electrodes	Electrode						•		HEC
High-frequency induction heating equipment	Power supply/ Heating coil	•			•				НЕВ
		1	1						нер

Technical Data

Global Supply Network

SMC has a comprehensive network in the global market.

We now have a presence of more than 560 branch offices and distributors in 83 countries and regions worldwide, such as Asia, Oceania, North/Central/South America, and Europe. With this global network, we are able to provide a global supply of our substantial range of products and high-quality customer service. We also provide full support to local factories, foreign manufacturing companies, and Japanese companies in each country.






SMC Thermo-chiller Variations

Lots of variations are available according to the users' requirements.

0	Temperature stability	Set temperature range [°C]					Coc	ling	capa	city [kW]					En instant	International	
Ser	Series			1.2	1.8	2.4	3	4	5	6	9	10	15	20	25	28	Environment	standards
	HRSE Basic type	±2.0	10 to 30	۲	•	•											Indoor use	Ç € (Only 230 VAC type)
	HRS Standard type	±0.1	5 to 40	•	•	•	•	•	•	•							Indoor use	Ç € (Only 60 Hz)
	HRS090 Standard type	±0.5	5 to 35								•						Indoor use	C € (400 V as standard)
	HRS100/150 Standard type	±1.0	5 to 35									•	•				Outdoor installation IPX4	€€ (400 V as standard)
	HRSH090 Inverter type	±0.1	5 to 40								•						Indoor use	(400 V as standard, 200 V as an option) (Only 200 V as an option)
	HRSH Inverter type	±0.1	5 to 35									•	•	•	•	•	Outdoor installation IPX4	(400 V as standard, 200 V as an option) (Only 200 V as an option)

Circulating Fluid/Facility Water Line Equipment



CONTENTS

HRS Series Standard Type



Thermo-chiller HRS Series

How to Order/Specifications

Single-phase 100/115 VAC	Page 35	5
Single-phase 200 to 230 VAC	Page 37	7
Cooling Capacity	Page 39	9
Heating Capacity	Page 41	I
Pump Capacity/Required Facility Water Flow Rate·····	Page 44	1
Dimensions	Page 45	5
Recommended External Piping Flow	Page 49	9
Cable Specifications	Page 49	9
Operation Display Panel	Page 50)
Alarm	Page 50)
Communication Functions	Page 51	I

Options

With Earth Leakage Breaker Page 52
With Automatic Fluid Fill Function Page 52
Applicable to Deionized Water Piping Page 52
High-Pressure Pump Mounted ······ Page 52
SI Unit Only Page 54
High-Temperature Environment Specification Page 54


Optional Accessories

Anti-Quake Bracket Page 57
2 Piping Conversion Fitting
(For Air-Cooled Refrigeration/Water-Cooled Refrigeration) ···· Page 57, 58
③ Piping Conversion Fitting (For Option) Page 58
④ Concentration Meter Page 59
(5) Bypass Piping Set ····· Page 59
6 Power Supply Cable Page 60
⑦ DI Filter Set ······ Page 61
(8) Electric Resistance Sensor Set/Electric Resistance Control Set … Page 62
(9) Electric Conductivity Sensor Set/Electric Conductivity Control Set Page 63
10 Particle Filter Set Page 64
1 Drain Pan Set (With Water Leakage Sensor) Page 65
12 Connector Cover Page 66
13 Analog Gateway Unit Page 66
(1) Replacement Type Dustproof Filter Set Page 66
(5) Separately-Installed Power Transformer Page 67
16 Filter for Circulating Fluid Fill Port Page 68

Cooling Capacity Calculation

Required Cooling Capacity Calculation	Page	69
Precautions on Cooling Capacity Calculation	Page	70
Circulating Fluid Typical Physical Property Values ····	Page	70

Specific Product Precautions Page 71



Specifications * There are different values from standard specifications. Refer to pages 52 to 54 for details.

		Model		HRS012-A□-10	HRS018-A□-10					
Cooling meth	nod			Air-cooled r	efrigeration					
Refrigerant				R407C	(HFC)					
Refrigerant of	harge		kg	0.32	0.33					
Control meth	od			PID control						
Ambient tem	perature/l	Humidity/Altitude ^{*1, 11}		Temperature: 5 to 40°C, Humidity: 30 to 70%, Altitude: less than 3000 m						
		ting fluid*2		Tap water, 15% ethylene	glycol aqueous solution*4					
		perature range*1	°C	5 to	40					
	Cooling	capacity (50/60 Hz)*3	W	1100/1300	1500/1700					
		capacity (50/60 Hz)*3	w	360/	450					
	Temperature stability*5 °C			±0						
Circulating			L/min	7 (0.13 MPa)/	7 (0.18 MPa)					
fluid	Pump	Maximum flow rate (50/60 Hz)	L/min	27/29						
system	Fump	Maximum pump head (50/60 Hz)	m	14/	19					
		Output	W	20	-					
_	Tank ca		L	Appro						
	Port size	e		Rc1/2						
	Fluid co	ontact material		Stainless steel, Copper (Heat exchanger brazing), Bronze, Alumina ceramic,						
	i iulu co			Carbon, PP, PE, POM, FKM, EPDM, PVC						
	Power s	supply		Single-phase 100 VAC (50 Hz), 100 to 115 VAC (60 Hz)						
	i ower a	, , , , , , , , , , , , , , , , , , ,		Allowable voltage	e range ±10%* ¹²					
Electrical		protector	Α		15					
system		e earth leakage breaker capacity*8	Α	1	=					
		perating current	Α	7.5/8.3	7.7/8.4					
		ower consumption (50/60 Hz)*3	kVA	0.7/0.8	0.8/0.8					
Noise level (50/60 Hz)*	k9	dB	58/						
				Fitting (for drain outlet) 1 pc., Input/output signal						
Accessories				Operation Manual (for installation/operation) 1, Quick Manual (with a clear case) 1,						
				Alarm code list sticker 1, Ferrite core (for communication) 1 pc.,						
				Power supply cable: Option (sold separately) to be ordered or prepared by the user.						
Weight*10			kg	40						
	used, use w	e present. ater that is compliant with the Water Q ir Conditioning Industry Association (JF		andards of the *7 The required minimum flow rate f	er outlet when the circulating fluid temperature is 20°C for maintaining the cooling capacity or temperature stability capacity and the temperature stability may not be satis					

- water system circulating type make-up water). Refer to "Specific Product Precautions" for other usable circulating fluids.
- *3 ① Ambient temperature: 25°C, ② Circulating fluid temperature: 20°C, ③ Circulating fluid at the rated flow, ④ Circulating fluid: Tap water
- Refer to the cooling capacity and heating capacity graphs on pages 39 and 41 for details. *4 Use a 15% ethylene glycol aqueous solution if operating in a place where the circulating fluid temperature is 10°C or less
- *5 Temperature at the thermo-chiller outlet when the circulating fluid flow is at the rated flow and the circulating fluid outlet and return port are directly connected. The installation environment and power supply are within the specification range and stable.
- fer to page 52.) *9 Front: 1 m, height: 1 m, stable with no load, Other conditions → See *3.

(sold separately).)


*10 Weight in the dry state without circulating fluids *11 If the product is used at an altitude of 1000 m or higher, refer to "Operating Environment/Storage Environment" (page 72) Item 14 "For altitudes of 1000 m or higher." *12 No continuous voltage fluctuation

*8 Purchase an earth leakage breaker with a sensitivity current of 15 mA or 30 mA separately. (A product with an optional earth leakage breaker (option B) is also available. Re-

fied if the flow rate is lower than the rated flow. (In such a case, use a bypass piping set

₿SMC

Thermo-chiller Standard Type HRS Series



Specifications * There are different values from standard specifications. Refer to pages 52 to 54 for details.

		Model		HRS012-W□-10	HRS018-W□-10						
Cooling meth	nod			Water-coole	d refrigeration						
Refrigerant				R4070	C (HFC)						
Refrigerant c	harge		kg	0.25	0.26						
Control meth	od			PID	control						
Ambient tem	perature/l	Humidity/Altitude*1		Temperature: 5 to 40°C, Humidity: 30 to 70%, Altitude: less than 3000 m							
	Circulat	ing fluid ^{*2}		Tap water, 15% ethylene	glycol aqueous solution*4						
	Set temp	perature range*1	°C	5 to 40							
	Cooling	capacity (50/60 Hz)*3	W	1100/1300	1500/1700						
	Heating	capacity (50/60 Hz)*3	w	360)/450						
	Tempera	ature stability*5	°C	±	0.1						
Circulating		Rated flow (50/60 Hz)*6, 7	L/min	7 (0.13 MPa)/7 (0.18 MPa)						
fluid	D	Maximum flow rate (50/60 Hz)	L/min	27	7/29						
system	Pump	Maximum pump head (50/60 Hz)	m	14/19							
		Output	w	2	00						
	Tank ca	pacity	L	Арр	rox. 5						
	Port size	9		R	c1/2						
	Fluid contact material			Stainless steel, Copper (Heat exchanger brazing), Bronze, Alumina ceramic, Carbon, PP, PE, POM, FKM, EPDM, PVC							
	Temper	ature range	°C		0 40						
	Pressur		MPa		to 0.5						
acility	Required flow rate (50/60 Hz)*11 L/min			8	12						
water	Inlet-outlet pressure differential of facility water MPa			-	r more						
system	Port size	· · ·	ini u	Rc3/8							
		ntact material		Stainless steel, Copper (Heat exchanger brazing), Bronze, Synthetic rubber							
				Single-phase 100 VAC (50 Hz), 100 to 115 VAC (60 Hz)							
	Power s	upply		Allowable voltage range $\pm 10^{\circ}$ * ¹²							
Electrical	Circuit r	protector	Α	15							
system		e earth leakage breaker capacity*8	A		15						
-,		perating current	A	7.5/8.3	7.7/8.4						
		wer consumption (50/60 Hz)*3	kVA	0.7/0.8	0.8/0.8						
Noise level (dB		3/55						
Accessories				Fitting (for drain outlet) 1 pc., Input/output signal connector 1 pc., Power supply connector 1 pc., Operation Manual (for installation/operation) 1, Quick Manual (with a clear case) 1, Alarm code list sticker 1, Ferrite core (for communication) 1 pc.,							
					ely) to be ordered or prepared by the user.						
Weight*10			kg		40						
Japan Refriger water system for other usabl	used, use wa ration and Ai circulating to e circulating	ater that is compliant with the Water C r Conditioning Industry Association (J ype - make-up water). Refer to "Specif	RA GL-02 fic Produc	andards of the *7 The required minimum flow rate 2-1994 cooling the Precautions" fied if the flow rate is lower that (sold separately).)	ller outlet when the circulating fluid temperature is 20°C of or maintaining the cooling capacity or temperature stabilit g capacity and the temperature stability may not be sati in the rated flow. (In such a case, use a bypass piping s eaker with a sensitivity current of 15 mA or 30 mA sep						
at the rated flo	w, ④ Circula	ting fluid: Tap water, 5 Facility water t	emperatu	re: 25°C rately. (A product with an optic	onal earth leakage breaker (option B) is also available. F						

Refer to the cooling capacity and heating capacity graphs on pages 39 and 41 for details. *4 Use a 15% ethylene glycol aqueous solution if operating in a place where the circulating

fluid temperature is 10°C or less. *5 Temperature at the thermo-chiller outlet when the circulating fluid flow is at the rated flow

and the circulating fluid outlet and return port are directly connected The installation environment and power supply are within the specification range and stable.

- fer to page 52.) *9 Front: 1 m, height: 1 m, stable with no load, Other conditions \rightarrow See *3.

 *10 Weight in the dry state without circulating fluids
 *11 The required flow rate when the cooling capacity load is applied at a circulating fluid temperature of 20°C, and circulating fluid rated flow and facility water temperature of 25°C *12 No continuous voltage fluctuation



HRS

HRS 100/150 HRS090 HRS-R

HRS200

HRSH090

HRSH

HRSE

HRR

HRI

HRZ

HRZD

HRW


HECR

HEC

HEB

HED

Technical Data



Specifications * There are different values from standard specifications. Refer to pages 52 to 54 for details.

~		Model	HRS012-AL-20	HKS018-A∐-20				HRS050-A□-20	HKS060-A∐-2					
		oling method		5 10 50		-cooled refrigerat	ion							
		rigerant			(HFC)			R410A (HFC)						
		rigerant charge kg	0.35	0.36	0.36	0.57	0.53	53 0.65 0.85						
-	-	ntrol method				PID control								
٩n	-	bient temperature/Humidity/Altitude*1, 1	² Temperature	Temperature: 5 to 40°C, High-temperature environment specification (option): 5 to 45°C, Humidity: 30 to 70%, Altitude: less than 3000 m Tap water, 15% ethylene glycol aqueous solution*4										
	-	Circulating fluid*2			Tap water, 15% e	, ,,	queous solution*	<4						
_		Set temperature range*1 °C				5 to 40								
stem	-	Cooling capacity (50/60 Hz)*3 W	1100/1300	1700/1900	2100/2400	2600/3200	3800/4200	4700/5100	4900/5900					
sysi	.–	Heating capacity (50/60 Hz)*3 W		530/650		600/640	900/1100	1100/1400	1000/1300					
		Temperature stability*5 °C				±0.1		T						
Ĕ		Rated flow (50/60 Hz)*6, 7 L/min		7 (0.		23 (0.24 MPa)/28 (0.32 MPa)	1 1							
E		Maximum flow rate (50/60 Hz) L/min	1	27/29		34	/40	31/42	29/38					
Ĕ	1	Maximum pump head (50/60 Hz) m			14/19 200			-	0					
Circulating fluid	L	Output W			550									
	Ŀ	Tank capacity L												
5	Ц	Port size		Rc1/2										
	1	Fluid contact material		Stainless steel, Copper (Heat exchanger brazing), Bronze, Alumina ceramic, Carbon, PP, PE, POM, FKM, EPDM, PVC										
system	1	Power supply		Single-phase 200 to 230 VAC (50/60 Hz) Allowable voltage range ±10%										
	١,	Circuit protector A		1	0	ŭ		20	30					
ectrical		Applicable earth leakage breaker capacity*8 A		1	0			20	30					
ğ	-	Rated operating current A	4.6/5.1	4.7/5.2	5.1/5.9	5.2/6.0	7.9/9.6	8/11	8.9/11.5					
Щ		Rated power consumption (50/60 Hz)*3 kVA	0.9/1.0	0.9/1.0	1.0/1.2	1.0/1.2	1.6/1.9	1.7/2.2	1.8/2.3					
No	_	se level (50/60 Hz)*9 dB		60/61	1	62/65	64/66	65/68	66/68					
Ac	cc	cessories	Č	Fitting (for drain outlet) 1 pc.* ¹¹ , Input/output signal connector 1 pc., Power supply connector 1 pc.* ¹² , Operation Manual (for installation/operation) 1, Quick Manual (with a clear case) 1* ¹² , Alarm code list sticker 1, Ferrite core (for communication) 1 pc., Power supply cable: Option (sold separately) to be ordered or prepared by the user.										
W	ei	ight ^{*10} kg		43		47	53	69	73					
1 2	No If t	o condensation should be present. tap water is used, use water that is compliant w ation and Air Conditioning Industry Association			rig- *7 The re		rate for maintaining tl	he circulating fluid ter he cooling capacity or	temperature stabili					

type - make-up water). Refer to "Specific Product Precautions" for other usable circulating fluids. *3 ① Ambient temperature: 25°C, ② Circulating fluid temperature: 20°C, ③ Circulating fluid

at the rated flow, 4 Circulating fluid: Tap water Refer to the cooling capacity and heating capacity graphs on pages 39 to 43 for details. *4 Use a 15% ethylene glycol aqueous solution if operating in a place where the circulating fluid temperature is 10°C or less.

*5 Temperature at the thermo-chiller outlet when the circulating fluid flow is at the rated flow and the circulating fluid outlet and return port are directly connected.

The installation environment and power supply are within the specification range and stable.


- flow rate is lower than the traded flow. (In such a case, use a bypass piping set (sold separately).) Purchase an earth leakage breaker with a sensitivity current of 30 mA separately. *8 (A product with an optional earth leakage breaker (option B) is also available.) *9 Front: 1 m, height: 1 m, stable with no load, Other conditions → See *3.

*10 Weight in the dry state without circulating fluids
 *11 It is not provided for the HRS050/060.

*12 It is not provided for the HRS040/050/060.
*13 If the product is used at an altitude of 1000 m or higher, refer to "Operating Environment/Storage Environment" (page 72) Item 14 "For altitudes of 1000 m or higher."



Thermo-chiller Standard Type HRS Series



Model	HRS012-W□-20	HRS018-W□-20	HRS024-W□-20	HRS030-W□-20	HRS040-W□-20	HRS050-W□-20	HRS060-W□-20						
Cooling method			Wate	er-cooled refriger	ation								
Refrigerant		R407C	(HFC)	•		R410A (HFC)							
Refrigerant charge kg	0.3	0.31	0.31	0.5	0.6	0.65	0.75						
Control method				PID control		·							
Ambient temperature/Humidity/Altitude*1		Temperatu	re: 5 to 40°C, Hu	midity: 30 to 70%	6, Altitude: less t	han 3000 m							
Circulating fluid*2		-	Tap water, 15% e	ethylene glycol ad	queous solution*	*4							
Set temperature range*1 °C				5 to 40		·							
Cooling capacity (50/60 Hz)*3 W Heating capacity (50/60 Hz)*3 W	1100/1300	1700/1900	2100/2400	2600/3200	3800/4200	4700/5100	4900/5900						
Heating capacity (50/60 Hz)*3 W		530/650		400/600	700/1000	1000	/1300						
				±0.1									
Bated flow (50/60 Hz)* ^{6, 7} L/min Maximum flow rate (50/60 Hz) L/min Maximum pump head (50/60 Hz) m Output Tank capacity Port size		7 (0.1	13 MPa)/7 (0.18	MPa)		23 (0.24 MPa)/28 (0.32 MPa)	23 (0.21 MPa)/28 (0.29 MPa)						
Maximum flow rate (50/60 Hz) L/min		27/29		34	/40	31/42	29/38						
.c Maximum pump head (50/60 Hz) m				5	0								
Te Output W			200			55	50						
Tank capacity L				Approx. 5									
Port size		Rc1/2											
Fluid contact material	Stainless steel, Copper (Heat exchanger brazing), Bronze, Alumina ceramic, Carbon, PP, PE, POM, FKM, EPDM, PVC												
E Temperature range °C													
Temperature range °C Pressure range MPa				0.3 to 0.5									
Bequired flow rate (50/60 Hz)*11 L/min	8	12	14	15	15	16	17						
Required flow rate (50/60 Hz)*11 L/min Inte-outlet pressure differential of facility water MPa Port size Fluid contact material				0.3 or more									
誓 Port size			Rc3/8			Rc	Rc1/2						
		Stainless ste		t exchanger brazi		nthetic rubber							
토 		Single-phase 200 to 230 VAC (50/60 Hz)											
Power supply			Allowa	ble voltage range	e ±10%								
			0			20							
Applicable earth leakage breaker capacity*8 A Rated operating current A		-	0			20							
ਤੋਂ Rated operating current A	4.6/5.1	4.7/5.2	5.1/5.9	5.2/6.0	6.9/8.4	7.6/10	7.6/10.4						
Rated power consumption (50/60 Hz)*3 kVA	0.9/1.0	0.9/1.0	1.0/1.2	1.0/1.2	1.5/1.7	1.5/2.0	1.5/2.1						
Noise level (50/60 Hz)*9 dB		60/61		62/65	64/66	65/68	66/68						
Accessories	Č Č	Fitting (for drain outlet) 1 pc.*12, Input/output signal connector 1 pc., Power supply connector 1 pc.*13, Operation Manual (for installation/operation) 1, Quick Manual (with a clear case) 1*13, Alarm code list sticker 1, Ferrite core (for communication) 1 pc., Power supply cable: Option (sold separately) to be ordered or prepared by the user.											
Weight ^{*10} kg		43		46	53	6	7						
 *1 No condensation should be present. *2 If tap water is used, use water that is compliant with eration and Air Conditioning Industry Association (J 			rig- *7 The re	equired minimum flow	rate for maintaining t	he circulating fluid ter the cooling capacity or emperature stability ma	temperature stability						

eration and Air Conditioning Industry Association (JRA GL-02-1994 cooling water system - circulating type - make-up water). Refer to "Specific Product Precautions" for other usable circulating fluids. *3 ① Ambient temperature: 25°C, ② Circulating fluid temperature: 20°C, ③ Circulating fluid

at the rated flow, @ Circulating fluid: Tap water, © Facility water temperature: 25°C Refer to the cooling capacity and heating capacity graphs on pages 39 to 43 for details.

*4 Use a 15% ethylene glycol aqueous solution if operating in a place where the circulating fluid temperature is 10°C or less.
*5 Temperature at the thermo-chiller outlet when the circulating fluid flow is at the rated flow

and the circulating fluid outlet and return port are directly connected. The installation environment and power supply are within the specification range and stable.

The specification of the cooling capacity and the temperature stability may not be satisfied if the flow rate is lower than the rated flow. (In such a case, use a bypass piping set (sold separately).) *8 Purchase an earth leakage breaker with a sensitivity current of 30 mA separately.

(A product with an optional earth leakage breaker (option B) is also available.) *9 Front: 1 m, height: 1 m, stable with no load, Other conditions → See *3.

*10 Weight in the dry state without circulating fluids
 *11 The required flow rate when the cooling capacity load is applied at a circulating fluid temperature of 20°C, and circulating fluid rated flow and facility water temperature of 25°C

*12 It is not provided for the HRS050/060. *13 It is not provided for the HRS040/050/060. HRS

HRS-R

HRS 100/150 HRS090

HRS200

HRSH090

HRSH

HRSE

HRR

HRI

HRZ

HRZD

HRW

HECR

HEC

HEB

HED


Technical Data

If the product is used at an altitude of 1000 m or higher, refer to "Operating Environment/Storage Environment" (page


72) Item 14 "For altitudes of 1000 m or higher."

Cooling Capacity For models with a high-pressure pump mounted (-T), the cooling capacity will decrease by about 300 W from each graph.


HRS012-A-10, HRS012-W-10 (Single-phase 100/115 VAC) (50 Hz)






































Thermo-chiller Standard Type HRS Series

- If the product is used at an altitude of 1000 m or higher, refer to "Operating Environment/Storage Environment" (page 72) Item 14 "For altitudes of 1000 m or higher."
- * For models with a high-pressure pump mounted (-T), the cooling capacity will decrease by about 300 W from each graph.

HRS024-A-20, HRS024-W-20 (Single-phase 200 to 230 VAC) (50 Hz)

Cooling Capacity



HRS

100/150 HRS090 HRS-R

HRS200

HRSH090

HRSH

HRSE

HRR

HRL

HRZ

HRZD

HRW


HECR


HEC


HEB


HED


Technical Data



























SMC

40

If the product is used at an altitude of 1000 m or higher, refer to "Operating Environment/Storage Environment" (page 72) Item 14 "For altitudes of 1000 m or higher."


* For models with a high-pressure pump mounted (-T), the cooling capacity will decrease by about 300 W from each graph.


HRS060-A-20, HRS060-W-20 (Single-phase 200 to 230 VAC) (50 Hz)




Heating Capacity


Cooling Capacity










SMC
















Heating Capacity


































(50 Hz)


Heating Capacity


HRS050-W-20 (Single-phase 200 to 230 VAC) (50 Hz)
























Pump Capacity


HRS⁰¹²₀₁₈ - ^A_W -10 (Single-phase 100/115 VAC)



HRS 030 - A -20 (Single-phase 200 to 230 VAC)




HRS060- ^A/_W-20 (Single-phase 200 to 230 VAC)




Required Facility Water Flow Rate


HRS012-W-¹⁰₂₀, HRS018-W-¹⁰₂₀, HRS024-W-20 HRS030-W-20, HRS040-W-20, HRS050-W-20 HRS060-W-20








HRS050- ^A_W-20 (Single-phase 200 to 230 VAC)




ACaution

Mechanical Seal Pump

The pump used for the thermo-chiller HRS050/060 series uses a mechanical seal with the fixed ring and rotary ring used for the shaft seal part. If foreign matter enter the gap between the seals, this may cause a trouble such as leakage from the seal part or pump lock. Therefore, it is strongly recommended to install the particle filter in the return piping of the chiller. **Mechanical seal**






HRS HRS 100/150 HRS090 HRS-R HRS200 HRSH090 HRSH HRSE HRR HRL HRZ HRZD HRW HECR HEC HEB HED Technical Data

* This is the facility water flow rate at the circulating fluid rated flow and the cooling capacity listed in the "Cooling Capacity" specifications.


Dimensions



多SMC


*1 The power supply cable is not provided. (The power supply connector is provided.)
 *2 The conversion fitting (R3/8 male thread) is provided.

Dimensions



SMC


Dimensions



Thermo-chiller Standard Type HRS Series


340

Dimensions



Recommended External Piping Flow

External piping circuit is recommended as shown below.



No.	Description	Size	Recommended part no.	Note		
1	Valve	Rc1/2	—	—		
2	Filter	Rc1/2 20 μm	HRS-PF	If foreign matter with a size of 20 μ m or more are likely to enter, install the particle filter. For the recommended filter, refer to the optional accessory HRS-PF $\Box\Box\Box$ (page 64).		
3	Flow meter	0 to 50 L/min	_	—		
4	Pressure gauge	0 to 1.0 MPa	—	—		
5	Others (pipe, hose, etc.)	ø15 or more	—	—		
6	Y-strainer	Y-strainer Rc1/2 #40 —		Install either the strainer or filter. If foreign matter with a size of 20 μm or more are likely to enter, install the particle		
6	Filter	Rc1/2 20 μm	FQ1011N-04-T020-B-X61*1	filter.		

*1 The filter shown above cannot be directly connected to the thermo-chiller. Install it in the user's piping system.

Cable Specifications

Power Cable Specifications


	Rated value for thermo-	chiller		Power cable examples			
Applicable model	Power supply	Applicable breaker rated current	Terminal block screw diameter	Cable size	Recommended crimped terminal	Optional accessories*1	
HRS012-□□-10-□ HRS018-□□-10-□	Single-phase 100 VAC (50 Hz) Single-phase 100 to 115 VAC (60 Hz)	15 A				HRS-CA001	
HRS012	Single-phase 200 to 230 VAC	10 A	M3.5	3 cores x 2.0 mm ² (3 cores x AWG14) * Including grounding cable	_	HRS-CA002	
HRS012	(50/60 Hz)	15 A			_	HN3-0A002	
HRS040-□-20-□ HRS050-□-20-□ HRS060-W□-20-□	Single-phase 200 to 230 VAC	20 A	M4	3 cores x 3.5 mm ² (3 cores x AWG12) * Including grounding cable	B5.5-4	HRS-CA004	
HRS060-A□-20-□	(50/60 Hz)	30 A	1014	3 cores x 5.5 mm ² (3 cores x AWG10) * Including grounding cable	no.5-4	_	

*1 The length of HRS-CA $\Box\Box\Box$ is 3 m.

(1)

Operation Display Panel

The basic operation of this unit is controlled through the operation display panel on the front of the product.



No.	Description	Function							
(1)	Digital display	PV Displays the circulating fluid current discharge temperature and pressure and alarm codes and other menu items (codes).							
	(7-segment, 4 digits)	SV Displays the circulating fluid discharge temperature and the set values of other menus.							
2	[°C] [°F] lamp	quipped with a unit conversion function. Displays the unit of display temperature (default setting: °C).							
3	[MPa] [PSI] lamp	Equipped with a unit conversion function. Displays the unit of display pressure (default setting: MPa).							
4	[REMOTE] lamp	Enables remote operation (start and stop) by communication. Lights up during remote operation.							
5	[RUN] lamp	Lights up when the product is started, and goes off when it is stopped. Flashes during stand-by for stop or anti-freezing function, or independent operation of the pump.							
6	[ALARM] lamp	Flashes with buzzer when alarm occurs.							
7	[🖃] lamp	Lights up when the surface of the fluid level indicator falls below the L level.							
8	[🕘] lamp	Equipped with a timer for start and stop. Lights up when this function is operated.							
9	[C] lamp	Equipped with a power failure auto-restart function, which restarts the product automatically after stopped due to a power failure, is provided. Lights up when this function is operated.							
10	[RUN/STOP] key	Makes the product start or stop.							
1	[MENU] key	Shifts the main menu (display screen of circulating fluid discharge temperature and pressure) and other menus (for monitoring and entry of set values).							
12	[SEL] key	Changes the item in menu and enters the set value.							
13	[▼] key	Decreases the set value.							
(14)	[▲] key	Increases the set value.							
(15)	[PUMP] key	Press the [MENU] and [RUN/STOP] keys simultaneously. The pump starts running independently to make the product ready for start-up (release the air).							
(16)	[RESET] key	Press the [▼] and [▲] keys simultaneously. The alarm buzzer is stopped and the [ALARM] indicator is reset.							

Alarm

This unit has 35 types of alarms as standard, and displays each of them by its alarm code on the PV screen with the [ALARM] lamp ([LOW LEVEL] lamp) lit up on the operation display panel. The alarm can be read out through communication.

Alarm code	Alarm message	Operation status	Alarm code	Alarm message	Operation status
AL01	Low level in tank	Stop*1	AL20	Memory error	Stop
AL02	High circulating fluid discharge temperature	Stop	AL21	DC line fuse cut	Stop
AL03	Circulating fluid discharge temperature rise	Continue*1	AL22	Circulating fluid discharge temperature sensor failure	Stop
AL04	Circulating fluid discharge temperature drop	Continue*1	AL23	Circulating fluid return temperature sensor failure	Stop
AL05	High circulating fluid return temperature (60°C)	Stop	AL24	Compressor intake temperature sensor failure	Stop
AL06	High circulating fluid discharge pressure	Stop	AL25	Circulating fluid discharge pressure sensor failure	Stop
AL07	Abnormal pump operation	Stop	AL26	Compressor discharge pressure sensor failure	Stop
AL08	Circulating fluid discharge pressure rise	Continue*1	AL27	Compressor intake pressure sensor failure	Stop
AL09	Circulating fluid discharge pressure drop	Continue ^{*1}	AL28	Pump maintenance	Continue
AL10	High compressor intake temperature	Stop	AL29	Fan motor maintenance*3	Continue
AL11	Low compressor intake temperature	Stop	AL30	Compressor maintenance	Continue
AL12	Low super heat temperature	Stop	AL31*2	Contact 1 input signal detection	Stop*1
AL13	High compressor discharge pressure	Stop	AL32*2	Contact 2 inputs signal detection	Stop*1
AL15	Refrigerating circuit pressure (high pressure side) drop	Stop	AL33*4	Water leakage	Stop*1
AL16	Refrigerating circuit pressure (low pressure side) rise	Stop	AL34*4	Electric resistance rise	Continue
AL17	Refrigerating circuit pressure (low pressure side) drop	Stop	AL35*4	Electric resistance drop	Continue
AL18	Compressor overload	Stop	AL36*4	Electric resistance sensor failure	Continue
AL19*2	Communication error*2	Continue*1		-	

*1 "Stop" or "Continue" are default settings. Users can change them to "Continue" and "Stop". For details, refer to the Operation Manual. *2 "AL19, AL31, AL32" are disabled in the default setting. If this function is necessary, it should be set by the user, referring to the Operation Manual. *4 This alarm function can be used when the option (sold separately) is used.

Please download the Operation Manual via our website, https://www.smcworld.com

HRS

HRS 100/150 HRS090 HRS-R

HRS200

HRSH090

HRSH

HRSE

HRR

HRL

HRZ

HRZD

HRW

HECR

HEC

HEB

HED

Technical Data

Communication Functions

	Item	Specifications						
Connector type (to the	product/to the socket (Accessory))	MC1,5/12-GF-3,5 / MC1,5/12-STF-3,5 (made by PHOENIX CONTACT)						
	Insulation method	Photocoupler						
	Rated input voltage	24 VDC						
Input signal	Operating voltage range	21.6 VDC to 26.4 VDC						
	Rated input current	5 mA TYP						
	Input impedance	4.7 kΩ						
Contact output	Rated load voltage	48 VAC or less/30 VDC or less						
signal	Maximum load current	500 mA AC/DC (Resistance load)						
Signal	Minimum load current	5 VDC 10 mA						
Ou	tput voltage	24 VDC ±10% 0.5 A MAX						
Circ	cuit diagram	$\begin{array}{c} 24 \text{ VDC} \\ (0.5 \text{ A MAX})^{*2} \\ 11 \\ 24 \text{ VCOM output} \\ 8 \\ 11 \text{ K}\Omega \\ 11$						

*1 The pin numbers and output signals can be set by the user. For details, refer to the Operation Manual.

*2 When using with optional accessories, depending on the accessory, the allowable current of 24 VDC devices will be reduced. Refer to the operation manual of the optional accessories for details.

Serial Communication

The serial communication (RS-485/RS-232C) enables the following items to be written and read out.

For details, refer to the Operation Manual for communication.

Writing	Readout	
Run/Stop Circulating fluid temperature setting (SV)	Circulating fluid present temperature Circulating fluid discharge pressure Electric resistance *1 Status information Alarm occurrence information	*1 When the optional accessory, "electric resistance sensor set" is used.

Item	Specifications						
Connector type	D-sub 9-pin, Female connector (Mounting screw: M2.6 x 0.45)						
Protocol	Modicon Modbus compliant/Simple communication protocol						
Standards	EIA standard RS-485	EIA standard RS-232C					
Circuit diagram	To the thermo-chiller User's equipment side	To the thermo-chiller User's equipment side					


* The terminal resistance of RS-485 (120 Ω) can be switched by the operation display panel. For details, refer to the Operation Manual. Do not connect other than in the way shown above, as it can result in failure.

Please download the Operation Manual via our website, https://www.smcworld.com

SMC

HRS Series **Options**

Options have to be selected when ordering the thermo-chiller. It is not possible to add them after purchasing the unit.



The required minimum flow rate for maintaining the cooling capacity or temperature stability *3


*4 Cooling capacity will decrease as pump power increases.

* When the option, high-pressure pump mounted, is selected, the weight increases by 4 kg for -10 type and 6 kg for -20 type.


* No change in external dimensions




Pump Capacity




HRS012/018/024-00-20-T



HRS030-00-20-T




HRS040-□□-20-T/MT




ACaution

Mechanical Seal Pump

The pump used for the option T/MT of the thermo-chiller HRS012 to 040 uses a mechanical seal with the fixed ring and rotary ring used for the shaft seal part. If foreign matter enter the gap between the seals, this may cause a trouble such as leakage from the seal part or pump lock. Therefore, it is strongly recommended to install the particle filter in the return piping of the chiller.





HRS012/018/024-00-20-MT



HRS030-□□-20-MT

SMC





HRS-R HRS 100/150 HRS090 HRS200 HRSH090 HRSH HRSE HRR HRL HRZ HRZD HRW HECR HEC HEB HED Technical Data

HRS

HRS Series **Optional Accessories**

Applicable Model List/Air-Cooled Refrigeration

• Optional accessories applicable to this model ★ Optional accessories recommended to be used for this model

No.	Desc	Description		Description			012-A 018-A		HRS024-A-20 HRS030-A-20		HRS050-A-20 HRS060-A-20	Ор	tion	Page
				-10	-20				пп3000-А-20	(for -J)	(for -T)	-		
(1)	Anti-guake bracket		HRS-TK001	•	•	•	•	—	—	-	-	- 57		
U	Anti-quake bracket		HRS-TK002	-	—	_	_	•	•	-	-	57		
		G thread conversion fitting set	HRS-EP001	•	•	•	•	•	—	-	—			
	Piping conversion fitting	NPT thread conversion fitting set	HRS-EP002	•	•	•	•	•	—	-	—	57		
2	(for air-cooled refrigeration)	G thread conversion fitting set	HRS-EP009	-	-	_	—	—	•	-	_	5/		
		NPT thread conversion fitting set	HRS-EP010	-	-	—	—	—	•	_	_]		
	Piping conversion fitting*1	G thread conversion fitting set	HRS-EP005	-	-	—	—	—	—	•	—			
(3)	(for automatic fluid fill port)	NPT thread conversion fitting set	HRS-EP006	-	-	_	—	—	—	•	_	50		
9	Piping conversion fitting*2	G thread conversion fitting set	HRS-EP007	-	-	_	_	_	_	_	•	- 58		
	(for drain outlet)	NPT thread conversion fitting set	HRS-EP008	-	-	_	_	_	_	_	•	1		
4	Concentration meter		HRZ-BR002	•	•	•	•	•	•	•	•	59		
			HRS-BP001	•	•	•	•	_	_	_	-			
(5)	Bypass piping set		HRS-BP004	-	_	_	_	•	•	_	_	- 59		
		For single-phase 100/115 VAC type	HRS-CA001	•	-	_	_	_	_	_	1_	1		
		For single-phase 200 VAC type	HRS-CA002	-	•	•	•	*3	_*3	_	_	1		
6)	Power supply cable	For single-phase 100/115 VAC type	HRS-CA003	•	-	_	_	_	_	_	_	60		
~		For single-phase 200 VAC type	HRS-CA004	_	_	_	_	•	•*4	_	_			
	Retaining clip		HRS-S0074	•	•	•	•	_	_	_	<u> </u>			
_			HRS-DP001	•	•	•	•	•	•	_	<u> </u>			
7	DI filter set		HRS-DP002	•	•	•	•	•	•	_	<u> </u>	61		
	Electric resistance sensor set		HRS-DI001	•	•	•	•	•	•			<u> </u>		
		With control function/bypass	HRS-DI003	•	•	•	•	_	_	_	<u> </u>	1		
8	Electric resistance control set		HRS-DI004	•	•	•	•			_	<u> </u>	62		
		With control function	HRS-DI005	•	•	•	•	•	•	_	<u> </u>	1		
	Electric conductivity sensor set		HRS-DI008	•	•	•	•	•	•		<u> </u>	+		
(9)		With control function/bypass	HRS-DI000	•	•	•		•	•			63		
9	Electric conductivity control set	With control function	HRS-DI009	•		•		_	_		<u> </u>	- 03		
		(#5) OUT side	HRS-PF001	•	•	•	•	•			<u> </u>			
		(#10) OUT side	HRS-PF002	-		•	•	•	•	<u> </u>	├──	1		
10	Particle filter set	(#10) 001 side (#5) IN side	HRS-PF002	•		•	•	•	-	_	<u> </u>	64		
		(#10) IN side	HRS-PF003	-	•	•	•	•	*	-	*	-		
				•	•	•	_		*		*			
1	Drain pan set	With water leakage sensor	HRS-WL001	-	•	•	•	_	_	_	<u> </u>	65		
			HRS-WL002	-	-	-	_	•	•		<u> </u>	<u> </u>		
12	Connector cover		HRS-BK001	•	•	•	•	_	_	-	<u> </u>	66		
			HRS-BK002	-	-	_	_	•	•		<u> </u>			
13			HRS-CV001	•	•	•	•	•	•		—	66		
14	Replacement type dustproof filter set		HRS-FL001	•	•	•	—	—	—	-	–	66		
	Replacement type dustproof filter		HRS-FL002	•	•	•		—		-	<u> </u>	<u> </u>		
			IDF-TR1000-1	•							<u> </u>	-		
			IDF-TR1000-2	•	-						<u> </u>			
_	Separately-installed*5		IDF-TR1000-3	•	-	-	-				<u> </u>			
(15)	power transformer		IDF-TR1000-4	•	<u> </u>	_	-	-	.*3		<u> </u>	67		
			IDF-TR2000-9		•	•	•				<u> </u>			
			IDF-TR2000-10		•	•	•							
			IDF-TR2000-11	_	•	•	•			_	_			
(16)	Filter for circulating fluid fill port		HRS-PF007	•	•	•	•	•	•	•		68		

*1 When option J is selected.
*2 When option T or the HRS050/060 is selected.

*2 When option 1 of the HRS050/060 is selected.
*3 For the HRS040/050/060 models: To be prepared by the user.
*4 Not applicable for the HRS060-A□-20. To be prepared by the user.
*5 This product does not have CE marking and is not compliant with UL standards.

Applicable Model List/Water-Cooled Refrigeration

• Optional accessories applicable to this model

★ Optional accessories recommended to be used for this model

No.	Desc	ription	Part no.	HRS		HRS024-W-20	HRS030-W-20	HRS040-W-20	HRS050-W-20 HRS060-W-20	· ·	tion	Page	HRS
			HRS-TK001	-10 ●	-20	•	•			(IOF -J)	(for -T)		Ц Ц
1	Anti-quake bracket		HRS-TK002			_	_	•	•	_	-	57	HRS-R
		G thread conversion fitting set	HRS-EP003	•	•	•	•	•	_		_		
	Dining conversion fitting	NPT thread conversion fitting set	HRS-EP004	•	•	•	•	•		_	-		HRS090
2	Piping conversion fitting (for water-cooled refrigeration)	G thread conversion fitting set	HRS-EP011	_	_	_	_	_	•	_	_	58	HS(
		NPT thread conversion fitting set	HRS-EP012	_	_			_	•	_	_		
	Piping conversion fitting*1	G thread conversion fitting set	HRS-EP005	-	_			_	•	•	-		150
	(for automatic fluid fill port)	NPT thread conversion fitting set	HRS-EP006	-	-				•	•	-		HRS 100/150
3	Piping conversion fitting*2		HRS-EP007	-	-			_	_	_	•	58	
	(for drain outlet)	NPT thread conversion fitting set	HRS-EP008	-	-					_	•		500
(4)	Concentration meter		HRZ-BR002	•	•	•	•	•	•	•	•	59	HRS200
			HRS-BP001	•	•	•	•	_	_	_	_		
5	Bypass piping set		HRS-BP004	_	_	_	_	•	•	_	-	59	60H
		For single-phase 100/115 VAC type	HRS-CA001	•	_			_	_	_	-		HRSH090
		For single-phase 200 VAC type	HRS-CA002	_	•	•	•	*3	*3	_	-		
6)	Power supply cable	For single-phase 100/115 VAC type	HRS-CA003	•	_	_	_	_	_		_	60	HSH
		For single-phase 200 VAC type	HRS-CA004	_	_			•	•*4		_	00	1 1
	Retaining clip		HRS-S0074	•	•	•	•		_		_		
			HRS-DP001	•	•	•	•	•	•				HRSE
7	DI filter set		HRS-DP002	•	•		•		•			61	1 11
	Electric resistance sensor set		HRS-DI002	•	•	•	•	•	•		_		\sim
		With control function/bypass	HRS-DI003	•	•		•	_	_	_	_	_	НВВ
8	Electric resistance control set		HRS-DI003	•	•	•	•				62	1 1	
	Electric resistance control set	With control function	HRS-DI004	•	•	•	•	•	•				\sim
	Electric conductivity sensor set		HRS-DI003	•	•	•	•	•	•				HBL
(9)		With control function/bypass	HRS-DI000	•	•	•	•	_	•		- 63	63	I
3	Electric conductivity control set	With control function	HRS-DI009	•	•		•	•	•			- 63	\sim
		(#5) OUT side	HRS-PF001	•	•	•	•	•	•				HRZ
		(#10) OUT side	HRS-PF002		•	•		•	•	<u> </u>			1
10	Particle filter set	(#10) 001 side (#5) IN side	HRS-PF002	•	•		•	•	-		*	64	
		(#10) IN side	HRS-PF004	-	-	•	•	•	*	_	*		HRZD
<u> </u>			HRS-WL001	•	•	•	•		×		X		E
1	Drain pan set	With water leakage sensor	HRS-WL001	-	-		-	_	_		-	65	
			HRS-BK001	•	•		•	• 	•		-		НВW
12	Connector cover		HRS-BK001	-				•	•			66	Ľ
(12)	Analog gateway unit		HRS-BK002 HRS-CV001	•	•	•	•	•	•		-	66	۲ ۲
0	Replacement type dustproof filter set			-					-			00	НЕСЯ
14)	Replacement type dustproof filter			-	-		—			-	-	_	Ξ
			 IDF-TR1000-1	•			—						
				•				-		<u> </u>			HEC
			IDF-TR1000-2 IDF-TR1000-3	•	-			-		<u> </u>	-		Ĺ
(15)	Separately-installed*5			-	-		—	-	.*3	<u> </u>	-	67	m
10	power transformer		IDF-TR1000-4	•	-	_	-			_	-	67	HEB
			IDF-TR2000-9		•	•	•	-		<u> </u>	<u> </u>		
			IDF-TR2000-10	-	•	•	•	-		<u> </u>			
10	Filter for airculating finish fills		IDF-TR2000-11	-	•	•	•	-	•	-	-	60	HED
16	Filter for circulating fluid fill port		HRS-PF007			•		•	•			68	

*1 When option J is selected.
*2 When option T or the HRS050/060 is selected.


*3 For the HRS040/050/060 models: To be prepared by the user.
*4 Not applicable for the HRS060-A□-20. To be prepared by the user.
*5 This product does not have CE marking and is not compliant with UL standards.

Technical Data

HRS Series

1) Anti-Quake Bracket

This bracket can be used to reduce product damage in the case of an earthquake. An anchor bolt (M8) suitable for the flooring material should be prepared separately by the user. (Anti-quake bracket thickness: 1.6 mm)



SMC

2 Piping Conversion Fitting (For Air-Cooled Refrigeration)

■ Conversion fitting for circulating fluid + Conversion fitting for drain outlet HRS012-A□-□, HRS018-A□-□, HRS024-A□-□, HRS030-A□-□, HRS040-A□-□

This fitting changes the port size for circulating fluid from Rc1/2 to G1/2 or NPT1/2, and for drain from Rc3/8 to G3/8 or NPT3/8. It is not necessary to purchase this when pipe thread type F or N is selected in "How to Order" since it is included in the product.

	Applicable model	
	G thread conversion fitting set	HRS012-A-□
HRS-EP001		
		HRS024-A-D
HRS-FP002	NPT thread conversion fitting set	HRS030-A-🗆
	in a mead conversion many set	HRS040-A-D


When the options, with automatic fluid fill function "-J", or high-pressure pump mounted "-T" are selected, purchase ③ piping conversion fitting (for option), too.

HRS050-A□-□, HRS060-A□-□

This fitting changes the port size for circulating fluid from Rc1/2 to G1/2 or NPT1/2, and for drain from Rc1/4 to G1/4 or NPT1/4. It is not necessary to purchase this when pipe thread type F or N is selected in "How to Order" since it is included in the product.

	Applicable model						
HRS-EP009	HRS-EP009 G thread conversion fitting set						
HRS-EP010	NPT thread conversion fitting set	HRS060-A-□					

When the option, with automatic fluid fill function "-J", is selected, purchase 3 piping conversion fitting (for option), too.



1 pc.

2 Piping Conversion Fitting (For Water-Cooled Refrigeration)

■ Conversion fitting for circulating fluid + Conversion fitting for facility water + Conversion fitting for drain outlet HRS012-W□-□, HRS018-W□-□, HRS024-W□-□, HRS030-W□-□, HRS040-W□-□

This fitting changes the port size for circulating fluid from Rc1/2 to G1/2 or NPT1/2, for facility water from Rc3/8 to G3/8 or NPT3/8, and for drain from Rc3/8 to G3/8 or NPT3/8. It is not necessary to purchase this when pipe thread type F or N is selected in "How to Order" since it is included in the product.

	Applicable model					
HRS-EP003	U U					
HRS-EP004	NPT thread conversion fitting set	HRS024-W-□ HRS030-W-□ HRS040-W-□				

When the options, with automatic fluid fill function "-J", or high-pressure pump mounted "-T" are selected, purchase ③ piping conversion fitting (for option), too.

HRS050-W□-□, HRS060-W□-□

This fitting changes the port size for circulating fluid or facility water from Rc1/2 to G1/2 or NPT1/2 and for drain from Rc1/4 to G1/4 or NPT1/4.

It is not necessary to purchase this when pipe thread type F or N is selected in "How to Order" since it is included in the product.

Part no.		Applicable model
HRS-EP011	G thread conversion fitting set	HRS050-W-
HRS-EP012	NPT thread conversion fitting set	HRS060-W-□

When the option, with automatic fluid fill function "-J", is selected, purchase ③ piping conversion fitting (for option), too.

③ Piping Conversion Fitting (For Option)

■ Conversion fitting for automatic fluid fill port

This fitting changes the port size for the option, with automatic fluid fill function "-J" from Rc3/8, Rc3/4 to G3/8, G3/4 or NPT3/8, NPT3/4.

It is not necessary to purchase this when pipe thread type F or N is selected in "How to Order" since it is included in the product.


Part no.		Applicable model
HRS-EP005	G thread conversion fitting set	HRS012-□-□-J HRS018-□-□-J HRS024-□-□-J HRS030-□-□-J
HRS-EP006	NPT thread conversion fitting set	HRS030


Conversion fitting for drain outlet

This fitting changes the port size for drain outlet for the option, high-pressure pump mounted "-T" from Rc1/4 to G1/4 or NPT1/4. It is not necessary to purchase this when pipe thread type F or N is selected in "How to Order" since it is included in the product.

Part no.		Applicable model	
HRS-EP007	G thread conversion fitting	HRS012	
HRS-EP008	NPT thread conversion fitting	HRS030-□-20- HRS040-□-20- HRS050-□-20* HRS060-□-20*	

*1 It is not necessary to purchase this when you purchase the HRS-EP009 to 012 since it is included in the product.





Technical Data

HRS

Ë

HRS-

HRS090

HRS 100/150

HRS200

HRSH090

HRSH

HRSE

HRR

HRI

HRZ

HRZD

HRW

HECR

HEC

HEB

HED

HRS Series

(4) Concentration Meter

This meter can be used to control the concentration of ethylene glycol aqueous solution regularly.

Part no.	Applicable model	Approx. 170 mm
HRZ-BR002	HRS012-□ HRS018-□ HRS024-□ HRS030-□ HRS040-□ HRS050-□ HRS060-□	Approx. 170 min

(5) Bypass Piping Set

When the circulating fluid goes below the rated flow (7 L/min for the HRS012, 018, 024, 030 and 23/28 L/min for the HRS040, 050, 060), cooling capacity will be reduced and the temperature stability will be badly affected. In such a case, use the bypass piping set. A high-pressure pump is also available.

Part no. Applicable mode	
	HRS012-□□-□
HRS-BP001	HRS018-□□-□
	HRS024-□□-□
	HRS030-□□-□


Parts List

No.	Description	Fluid contact material	Qty.
	Bypass tube	PFA	1
	(Part no.: TL0806)	FFA	(Approx. 700 mm)
2	Outlet piping (With ball valve)	Stainless steel	1
3	Return port piping	Stainless steel	1
(4)	Nipple (Size: 1/2)	Stainless steel	2

Part no.	Applicable model
HRS-BP004	HRS040-□□-□
	HRS050-□□-□
	HRS060-□□-□


Parts List

No.	Description	Fluid contact material	Qty.
1	Hose	PVC	1 (Approx. 700 mm)
2	Outlet piping (With ball valve)	Stainless steel	1
3	Return port piping	Stainless steel	1
4	Nipple (Size: 1/2)	Stainless steel	2
(5)	Hose band	—	2



6 Power Supply Cable

■ For single-phase 100/115 VAC type




С

 \bigcirc

() G1

Thermo-chiller side



Applicable to retaining clip.

Part no.	Applicable model
HRS-CA004	HRS040-□□-20 HRS050-□□-20 HRS060-W□-20


 Not available for the HRS060-A□-20. To be prepared by the user.


Not applicable to retaining clip.

Retaining clip

Holds the connector on the thermo-chiller side in position.

Part no.	Applicable power supply cable		
	HRS-CA002		
HRS-S0074	HRS-CA003		
	Power supply connector for accessory		





Par	ts	List
		_

No.	Description	
1	Retaining clip	
2	Holding screw	

Approx. 3 m

	L
Approx. 100 mm	HBS
User's equipment side	
Approx. 100 mm User's equipment side	


HRS

⑦ DI Filter Set

It is possible to retain the level of electric resistance and electric conductivity by flowing the circulating through the ion replacement resin (DI filter). The set parts are in order to install DI filter to bypass circuit and flow the fixed rate of the circulating fluid to DI filter. It is not to control the value of electric resistance and electric conductivity. (Replacement cartridge: HRS-DF001)


Stainless steel type

Suitable for locations with dusty atmospheres.



Resin type

Lightweight and compact Can be installed in combination with the HRS-PF001, PF002.



Qty.

1

1

1

1

4

2

1

1

2

1

8 Electric Resistance Sensor Set/Electric Resistance Control Set (When the electrical resistivity of the circulating fluid is 1 MΩ-cm or higher)

Option M needs to be selected at the time of purchase.

This product can be used to display, maintain, and control the electric resistivity of the circulating fluid (deionized water). The function differs according to the model (Refer to the table below). Refer to the Operation Manual for details.

Part no.	Applicable model
HRS-DI001 HRS-DI005	HRS012- HRS018- HRS024- HRS030- HRS040- HRS040- HRS050- HRS060-
HRS-DI003 HRS-DI004	HRS012-□□-□ HRS018-□□-□ HRS024-□□-□ HRS030-□□-□

List of Function

Optiona accessori		Description	Electric resistivity display*1, *2	Electric resistivity maintenance	Electric resistivity control	Bypass ^{*3}
HRS-DI0	01	Electric resistance sensor set	0	×	×	×
HRS-DI0	03	Electric resistance control set	0	0	0	0
HRS-DI0	04	Electric resistance sensor set	0	0	×	0
HRS-DI0	05	Electric resistance control set	0	0	0	×
4 Disular		and in Orthold F Michael				

*1 Display range is 0 to 4.5 M Ω ·cm.


*2 Readout using serial communications (RS-485/RS-232C) can be performed.

*3 This function is dedicated for the HRS-BP001 and cannot be used for the HRS040/050/060.


Specifications

	Electric resistance sensor set	Electric resistance control set			
Measurement range of electric resistivity	0 to 4.5 MΩ⋅cm				
Set range of electric resistivity target	_	0.2 to 4.0 MΩ⋅cm			
Set range of electric resistivity hysteresis	_	0.1 to 0.9 MΩ⋅cm			
Operating temperature range (Circulating fluid temperature)	re) 5 to 60°C				
Operating pressure range	0.5 MPa or less				
Current consumption	100 mA or less 400 mA or less				
Installation environment	Indoors				

[Mounting example: HRS012-A-20-M + HRS-DI001]



[Mounting example: HRS012-A-20-M + HRS-DI003]



Darte Liet

No. Departmention		Fluid contact	Qty.			
No.	Description	material	DI001	DI003	DI004	DI005
	DI filter vessel	Stainless steel	—	1	1	_
U	Di liller vesser	PC, PP	—	—	—	1
2	Mounting bracket	—	—	1	1	1
3	DI filter inlet tube	PFA, POM	—	1	1	1
4	DI filter outlet tube	PFA, POM	—	1	1	1
(5)	Bypass tube	PFA	—	1	1	_
6	Mounting screw (M6 screw)	—	—	2	2	
\bigcirc	Mounting screw (M5 screw)	—	—	2	2	6
8	Electric resistance sensor	Stainless steel, PPS	1	1	1	1
9	Solenoid valve for control	Stainless steel, EPDM	—	1	-	1
10	Nipple (Size: 1/2)	Stainless steel	1	2	2	2
1	DI filter cartridge (Part no.: HRS-DF001)*1	PP, PE	_	1	1	1

*1 The product should be replaced when it can no longer preserve the electrical resistivity set value.

Technical Data

(9) Electric Conductivity Sensor Set/Electric Conductivity Control Set

This product can be used to display, maintain, and control the electric conductivity of the circulating fluid (deionized water). The function differs according to the model (Refer to the table below). Refer to the Operation Manual for details.

Part no.	Applicable model	
HRS-DI008 HRS-DI011	HRS012 HRS018 HRS024 HRS030 HRS040 HRS050 HRS060	
HRS-DI009	HRS012-□□-□ HRS018-□□-□ HRS024-□□-□ HRS030-□□-□	

List of Function

Optional accessories		Electric conductivity display*1, *2	Electric conductivity maintenance	Electric conductivity control	Bypass*3
HRS-DI008	Electric conductivity sensor set	0	×	×	×
HRS-DI009	Electric conductivity control set	0	0	0	0
HRS-DI011	Electric conductivity control set	0	0	0	×


*1 Display range is 2 to 48 μS/cm.

*2 Readout using serial communications (RS-485/RS-232C) can be performed.
*3 This function is dedicated for the HRS-BP001 and cannot be used for the HRS040/050/060.


Specifications

	Electric conductivity sensor set	Electric conductivity control set		
Measurement range of electric conductivity	2.0 to 48.0 μS/cm			
Set range of electric conductivity target	_	5.0 to 45.0 µS/cm		
Set range of electric conductivity hysteresis	- 2.0 to 10.0 μS/cm			
Operating temperature range (Circulating fluid temperature)	5 to 60°C			
Operating pressure range	0.5 MPa or less			
Current consumption	100 mA or less 400 mA or less			
Installation environment	Indoors			

[Mounting example: HRS012-A-20 + HRS-DI008]



[Mounting example: HRS012-A-20 + HRS-DI009]



Parts List

SMC

No.	Description	Fluid contact	Qty.			
INO.	Description	material	DI008	DI009	DI011	
	DI filter vessel	Stainless steel	—	1	—	
\square	DI filter vessel	PC, PP	—		1	
2	Mounting bracket	—	—	1	1	
3	DI filter inlet tube	PFA, POM	—	1	1	
(4)	DI filter outlet tube	PFA, POM	—	1	1	
(5)	Bypass tube	PFA	—	1	—	
6	Mounting screw (M6 screw)	—	—	2	—	
\bigcirc	Mounting screw (M5 screw)	—	—	2	6	
8	Electric conductivity sensor	Stainless steel, PPS	1	1	1	
9	Solenoid valve for control	Stainless steel, EPDM	—	1	1	
10	Nipple (Size: 1/2)	Stainless steel	1	2	2	
1	DI filter cartridge (Part no.: HRS-DF001)*1	PP, PE	_	1	1	

*1 The product should be replaced when it can no longer preserve the electrical conductivity set value.

HRS

HRS-R

HRS 100/150 HRS090

HRS200

HRSH090

HRSH

HRSE

HRR

HRI

HRZ

HRZD

HRW

HECR

HEC

HEB

HED

Technical Data

10 Particle Filter Set

(1)

(2)

(3)

4

5

6

(7)


(8)

Tapping screw

Sealant tape

Handle

This set can be used to remove foreign matter from the circulating fluid.



4

1

1


PTFE

SMC


When -H is selected

1 Drain Pan Set (With Water Leakage Sensor)

Drain pan for the thermo-chiller. Liquid leakage from the thermo-chiller can be detected by mounting the attached water leakage sensor. Anchor bolt (M8) suitable for the flooring material should be prepared separately by the user.



Par	Parts List							
No.	Description							
1	Drain pan							
2	Thermo-chiller fixing bracket (2 pcs.)							
3	Drain pan fixing bracket (4 pcs.)							
(4)	Water leakage sensor							
5	Bracket fixing screw (M6 screw, 12 pcs.)							




Parts List

No.	Description			
1	Drain pan			
(2) Thermo-chiller fixing bracket(2 pcs.)				
3	Drain pan fixing bracket (4 pcs.)			
4	Water leakage sensor			
5	Bracket fixing screw (M6 screw, 12 pcs.)			



Optional Accessories HRS Series

12 Connector Cover



13 Analog Gateway Unit

This is an expansion unit for adding analog communication functions. "Analog communication, contact input/output" functions can be used.

Analog communication


The set circulating fluid temperature can be changed by entering the analog voltage.


Converts the current circulating fluid temperature and current electric resistance value (*1) to an analog voltage for output. *1 Displayed when optional "Electric resistance sensor set/HRS-DI001, DI003, DI004, and DI005" are used.


Contact input/output

The Run/Stop of the thermo-chiller HRS series can be operated by a contact signal.

The contact signal of the operation status, alarm occurrence status and the TEMP READY status can also be output.







Replacement Type Dustproof Filter Set

A disposable dustproof filter is mounted instead of the dustproof net on the front panel.

Part no.	Applicable model	
	HRS012-A□-□	
HRS-FL001	HRS018-A□-□	
	HRS024-A□-□	

Parts List

No.	Description	Description Part no. N				
1	Replacement type dustproof filter set	HRS-FL001	A front panel with hook-and-loop fastener for holding the filter, 5 filters are included. (No dustproof net is included.)			
2	Replacement type dustproof filter	HRS-FL002	5 filters per set Size: 300 x 370			





15 Separately-Installed Power Transformer


This transformer does not have CE marking and is not compliant with UL standards.


Specifications

Dartina	Anniachte medel	Inlet voltage		voltage	Outlet voltage			
Part no.	Applicable model	Volume	Туре	50 Hz	60 Hz	50 Hz	60 Hz	
IDF-TR1000-1	HRS012-□-10 HRS018-□-10			110 VAC	120 VAC	100 VAC	100, 110 VAC	
IDF-TR1000-2		1 kVA		240 VAC	240 to 260 VAC			
IDF-TR1000-3		S018-□-10	Single- phase	380, 400, 415 VAC	380 to 420 VAC			
IDF-TR1000-4				420, 440, 480 VAC	420 to 520 VAC			
IDF-TR2000-9	HRS012-□-20 HRS018-□-20 HRS024-□-20 HRS030-□-20	HRS012-□-20			—	240 VAC		
IDF-TR2000-10		HRS024-□-20 2 kVA	2 kVA	380, 400, 415 VAC	380 to 400, 400 to 415, 415 to 440 VAC	200 VAC	200, 220 VAC	
IDF-TR2000-11				440, 460 VAC	440 to 460, 460 to 500 VAC			


* For the HRS040/050/060 models: To be prepared by the user.


IDF-TR1000-1






IDF-TR1000-3, 4












IDF-TR1000-2






IDF-TR2000-9

15






16 Filter for Circulating Fluid Fill Port

Prevents foreign matter from entering the tank when supplying the circulating fluid. Can be used just by fitting into the circulating fluid fill port.

■ Filter for circulating fluid fill port HRS-PF007

Material	Stainless steel 304, Stainless steel 316
Mesh size	200





68

SMC

HRS Series Cooling Capacity Calculation

Required Cooling Capacity Calculation

Example 1: When the heat generation amount in the user's equipment is known.

The heat generation amount can be determined based on the power consumption or output of the heat generating area — i.e. the area requiring cooling — within the user's equipment.*1: Current

① Derive the heat generation amount from the power consumption.

Power consumption P: 1000 [W]

Q = P = 1000 [W]

Cooling capacity = Considering a safety factor of 20%, 1000 [W] x 1.2 = 1200 [W]


② Derive the heat generation amount from the power supply output.
Power supply output VI: 1.0 [kVA]

 $Q = P = V \times I \times Power factor$

In this example, using a power factor of 0.85:

Cooling capacity = Considering a safety factor of 20%, **850** [W] \times 1.2 = 1020 [W]

850 [W] x 1.2 = 1020 [W]



 $\ensuremath{\textcircled{3}}$ Derive the heat generation amount from the output.

Output (shaft power, etc.) W: 800 [W]

$$Q = P = \frac{W}{Efficiency}$$

In this example, using an efficiency of 0.7:

Cooling capacity = Considering a safety factor of 20%, 1143 [W] x 1.2 = 1372 [W]

*1 The examples above calculate the heat generation amount based on the power consumption. The actual heat generation amount may differ due to the structure of the user's equipment. Be sure to check it carefully.

Example 2: When the heat generation amount in the user's equipment is not known.

Obtain the temperature difference between inlet and outlet by circulating the circulating fluid inside the user's equipment.


Theat generation amount by user's equipme	
Circulating fluid	: Tap water*1
Circulating fluid mass flow rate qm	: (= ρ x q v ÷ 60) [kg/s]
Circulating fluid density ρ	: 1 [kg/dm³]
Circulating fluid (volume) flow rate qv	: 10 [dm³/min]
Circulating fluid specific heat C	: 4.2 x 10 ³ [J/(kg·K)]
Circulating fluid outlet temperature T1	: 293 [K] (20 [°C])
Circulating fluid return temperature T2	: 295 [K] (22 [°C])
Circulating fluid temperature difference $\Delta \textbf{T}$: 2.0 [K] (= T 2 – T 1)
Conversion factor: minutes to seconds (SI	units): 60 [s/min]

*1 Refer to page 70 for the typical physical property value of tap water or other circulating fluids.

$$\mathbf{Q} = \mathbf{q}_{\mathrm{m}} \mathbf{x} \mathbf{C} \mathbf{x} (\mathbf{T}_2 - \mathbf{T}_1)$$

$$=\frac{\rho \ x \ q_{V} \ x \ C \ x \ \Delta T}{60} = \frac{1 \ x \ 10 \ x \ 4.2 \ x \ 10^{3} \ x \ 2.0}{60}$$

Cooling capacity = Considering a safety factor of 20%,



Example of conventional units (Reference)				
Circulating fluid (volume) flow rate q_v Circulating fluid specific heat C Circulating fluid outlet temperature T1 Circulating fluid return temperature T2 Circulating fluid temperature difference ΔT Conversion factor: hours to minutes	: Tap water*1 : $(= \rho \times q_v \times 60) [kgf/h]$: 1 [kgf/L] : 10 [L/min] : 1.0 x 10 ³ [cal/(kgf.°C)] : 20 [°C] : 22 [°C] : 2.0 [°C] (= T ₂ - T ₁) : 60 [min/h]			
Conversion factor: kcal/h to kW $Q = \frac{q_{m} x C x (T_{2} - T_{1})}{860}$ $= \frac{\gamma x q_{v} x 60 x C x \Delta T}{860}$ $= \frac{1 x 10 x 60 x 1.0 x 10^{3} x 2.0}{860}$: 860 [(cal/h)/W]			
= 1200000 [cal/h] 860				

Cooling capacity = Considering a safety factor of 20%, 1400 [W] x 1.2 = 1680 [W]

Required Cooling Capacity Calculation

Example 3: When there is no heat generation, and when cooling the object below a certain temperature and period of t


Heat quantity by cooled substance (per unit time) Q Cooled substance	: Unknown [W] ([J/s]) : Water	Example of c
	: (= ρ x V) [kg]	Heat quantity by c
Cooled substance density p	: 1 [kg/L]	Cooled substar
Cooled substance total volume V	: 20 [dm ³]	Cooled substar
Cooled substance specific heat C	: 4.2 x 10 ³ [J/(kg·K)]	Cooled substar
Cooled substance temperature when cooling begins To	: 305 [K] (32 [°C])	Cooled substar
Cooled substance temperature after t hour Tt	: 293 [K] (20 [°C])	Cooled substar
Cooling temperature difference $\Delta \mathbf{T}$: 12 [K] (= T 0 – T t)	Cooled substar
•	: 900 [s] (= 15 [min])	cooling begins

* Refer to the following for the typical physical property values by circulating fluid.

$$\mathbf{Q} = \frac{\mathbf{m} \mathbf{x} \mathbf{C} \mathbf{x} (\mathbf{T}_0 - \mathbf{T}_t)}{\Delta t} = \frac{\rho \mathbf{x} \mathbf{V} \mathbf{x} \mathbf{C} \mathbf{x} \Delta \mathbf{T}}{\Delta t}$$
$$= \frac{1 \mathbf{x} 20 \mathbf{x} 4.2 \mathbf{x} 10^3 \mathbf{x} 12}{900} = 1120 \text{ [J/s]} \approx 1120 \text{ [W]}$$

Cooling capacity = Considering a safety factor of 20%,

1120 [W] x 1.2 = 1344 [W]



time.						
Example of conventional units (R	eference)					
Heat quantity by cooled substance (per unit to Cooled substance Cooled substance weight m Cooled substance weight volume ratio Cooled substance total volume V Cooled substance specific heat C Cooled substance temperature when cooling begins To Cooled substance temperature after the Cooling temperature difference Δ T Cooling time Δ t Conversion factor: hours to minutes Conversion factor: kcal/h to kW	: Water : (= ρ x V) [kgf] : 1 [kgf/L] : 20 [L] : 1.0 x 10 ³ [cal/(kgf·°C)] : 32 [°C]					
$\mathbf{Q} = \frac{\mathbf{m} \mathbf{x} \mathbf{C} \mathbf{x} (\mathbf{T}_0 - \mathbf{T}_t)}{\Delta t \mathbf{x} 860} = \frac{\gamma \mathbf{x} \mathbf{V} \mathbf{x} 60 \mathbf{x} \mathbf{C} \mathbf{x} \Delta \mathbf{T}}{\Delta t \mathbf{x} 860}$						
= <u>1 x 20 x 60 x 1.0 x 10³ x 12</u>						
15 x 860						

Cooling capacity = Considering a safety factor of 20%,

This is the calculated value by changing the fluid temperature only. Thus, it varies substantially depending on the water bath or piping shape.

Precautions on Cooling Capacity Calculation

1. Heating capacity

When the circulating fluid temperature is set above room temperature, it needs to be heated by the thermo-chiller. The heating capacity depends on the circulating fluid temperature. Consider the radiation rate and heat capacity of the user's equipment and check beforehand if the required heating capacity is provided.

2. Pump capacity

<Circulating fluid flow rate>

Circulating fluid flow rate varies depending on the circulating fluid discharge pressure. Consider the installation height difference between the thermo-chiller and the user's equipment, and the piping resistance such as circulating fluid pipings, or piping size, or piping curves in the machine. Check beforehand if the required flow is achieved, using the pump capacity curves.

<Circulating fluid discharge pressure>

Circulating fluid discharge pressure has the possibility to increase up to the maximum pressure in the pump capacity curves. Check beforehand if the circulating fluid pipings or circulating fluid circuit of the user's equipment are fully durable against this pressure.

Circulating Fluid Typical Physical Property Values

1. This catalog uses the following values for density and specific heat in calculating the required cooling capacity.

 ρ : 1 [kg/L] (or, using conventional units, weight volume ratio $\gamma = 1$ [kg/L]) **C**: 4.19 x 10³ [J/(kg-K)] (or, using conventional units, 1 x 10³ [cal/(kgf·°C)]) Density

Specific heat

2. Values for density and specific heat change slightly according to temperature shown below. Use this as a reference. Water 15% Ethylene Glycol Aqueous Solution

Physical property value	Density ρ	Specific heat C	Conventional units		
Temperature	[kg/L]	[J/(kg⋅K)]	Weight volume ratio γ [kgf/L]	Specific heat C [cal/(kgf.°C)]	
5°C	1.00	4.2 x 10 ³	1.00	1 x 10 ³	
10°C	1.00	4.19 x 10 ³	1.00	1 x 10 ³	
15°C	1.00	4.19 x 10 ³	1.00	1 x 10 ³	
20°C	1.00	4.18 x 10 ³	1.00	1 x 10 ³	
25°C	1.00	4.18 x 10 ³	1.00	1 x 10 ³	
30°C	1.00	4.18 x 10 ³	1.00	1 x 10 ³	
35°C	0.99	4.18 x 10 ³	0.99	1 x 10 ³	
40°C	0.99	4.18 x 10 ³	0.99	1 x 10 ³	

Physical property value	Density ρ	Specific heat C	Conventi	onal units
Temperature	[kg/L]	[J/(kg·K)]	Weight volume ratio y [kgf/L]	Specific heat C [cal/(kgf.°C)]
5°C	1.02	3.91 x 10 ³	1.02	0.93 x 10 ³
10°C	1.02	3.91 x 10 ³	1.02	0.93 x 10 ³
15°C	1.02	3.91 x 10 ³	1.02	0.93 x 10 ³
20°C	1.01	3.91 x 10 ³	1.01	0.93 x 10 ³
25°C	1.01	3.91 x 10 ³	1.01	0.93 x 10 ³
30°C	1.01	3.91 x 10 ³	1.01	0.94 x 10 ³
35°C	1.01	3.91 x 10 ³	1.01	0.94 x 10 ³
40°C	1.01	3.92 x 10 ³	1.01	0.94 x 10 ³

Shown above are reference values. Contact circulating fluid supplier for details.





Be sure to read this before handling the products. Refer to page 513 for safety instructions and pages 514 to 517 for temperature control equipment precautions.

Design

\land Warning

1. This catalog shows the specifications of a single unit.

- 1) Check the specifications of the single unit (contents of this catalog) and thoroughly consider the adaptability between the user's system and this unit.
- 2) Although a protection circuit as a single unit is installed, prepare a drain pan, water leakage sensor, discharge air facility, and emergency stop equipment, depending on the user's operating conditions. Also, the user is requested to carry out a safety design for the whole system.

2. When attempting to cool areas that are open to the atmosphere (tanks, pipes), plan your piping system accordingly.

When cooling open-air external tanks, arrange the piping so that there are coil pipes for cooling inside the tanks and to carry back the entire flow volume of circulating fluid that is released.

3. Use non-corrosive material for circulating fluid contact parts.

The recommended circulating fluid is tap water or 15% ethylene glycol aqueous solution. Using corrosive materials such as aluminum or iron for fluid contact parts such as piping may cause clogging or leakage in the circulating fluid circuit. Therefore, take sufficient care when selecting fluid contact part materials such as piping.

4. Design the piping so that no foreign matter enters the chiller.

If foreign matter, such as scales in the piping, enters the circulating fluid, this may cause the pump to malfunction. In particular, when the option T (High-pressure pump mounted) or HRS050/060 is used, it is strongly recommended to install the particle filter.

Selection

\land Warning

1. Model selection

When selecting a thermo-chiller model, the amount of heat generation from the user's equipment must be known. Obtain this value, referring to "Cooling Capacity Calculation" on pages 69 and 70 before selecting a model.

Handling

\land Warning

1. Thoroughly read the operation manual.

Read the operation manual completely before operation, and keep the manual where it can be referred to as necessary.

Transportation/Carriage/Movement


\land Warning

- 1. This product is heavy. Pay attention to safety and the position of the product when it is transported, carried, and moved.
- 2. Read the operation manual carefully before moving the product after unpacking.

\land Caution

1. Never put the product down on its side as this may cause failure.

The product will be delivered in the packaging shown below.



Model	Weight [kg]*1	Dimensions [mm]
HRS012-□□-10 HRS018-□□-10	49	Height 790 x Width 470 x Depth 580
HRS012-□□-20 HRS018-□□-20 HRS024-□□-20	52	Height 790 x Width 470 x Depth 580
HRS030-A□-20	56	Height 830 x Width 470 x Depth 580
HRS030-W□-20	55	neight 650 x width 470 x Depth 580
HRS040-□□-20	63	Height 900 x Width 450 x Depth 670
HRS050-A□-20	80	
HRS050-W□-20	78	Height 1160 x Width 450 x Depth 670
HRS060-A□-20	84	Height 1160 x Width 450 x Depth 670
HRS060-W□-20	78	

*1 For models with an option, the weight increases as shown below.

Option symbol	Description	Additional weight	
-B With earth leakage breaker		No additional weight	
-J	With automatic fluid fill function	+1 kg	
-M	Applicable to deionized water piping	No additional weight	
-т	High-pressure pump mounted (100 V type)	+4 kg	
-1	High-pressure pump mounted (200 V type)	+6 kg	
-G	High-temperature environment specification	No additional weight	



Be sure to read this before handling the products. Refer to page 513 for safety instructions and pages 514 to 517 for temperature control equipment precautions.

Operating Environment/Storage Environment

\land Warning

1. Do not use in the following environment as it will lead to a breakdown.

- 1) Outdoors
- 2) In locations where water, water vapor, salt water, and oil may splash on the product
- 3) In locations where there are dust and particles
- In locations where corrosive gases, organic solvents, chemical fluids, or flammable gases are present (This product is not explosion proof.)
- 5) In locations where the ambient temperature exceeds the limits as mentioned below

During transportation/storage: 0 to 50°C (But as long as water or circulating fluid are not left inside the pipings)

During operation: 5 to 40° C (When option G, high-temperature environment specification, is selected: 5 to 45° C)

 6) In locations where the ambient humidity is out of the following range or where condensation occurs During transportation/storage: 15 to 85%

During operation: 30 to 70%

- 7) In locations which receive direct sunlight or radiated heat
- 8) In locations where there is a heat source nearby and the ventilation is poor
- 9) In locations where temperature substantially changes
- In locations where strong magnetic noise occurs (In locations where strong electric fields, strong magnetic fields, and surge voltage occur)
- 11) In locations where static electricity occurs, or conditions which make the product discharge static electricity
- 12) In locations where high frequency occurs
- 13) In locations where damage is likely to occur due to lightning
- 14) In locations at an altitude of 3000 m or higher (Except during storage and transportation)
 - * For altitudes of 1000 m or higher
 - Because of lower air density, the heat radiation efficiencies of the devices in the product will be lower in the location at an altitude of 1000 m or higher. Therefore, the maximum ambient temperature to use and the cooling capacity will lower according to the descriptions in the table below.

Select the thermo-chiller considering the descriptions.

- ① Upper limit of ambient temperature: Use the product in ambient temperature of the described value or lower at each altitude.
- ② Cooling capacity coefficient: The product's cooling capacity will lower to one that multiplied by the described value at each altitude.

Altitude [m]	① Upper limit of ambient temperature [°C] 40°C 45°C products (For high-temperature environment specification, Option G)		⁽²⁾ Cooling capacity coefficient	
Less than 1000 m	40	45	1.00	
Less than 1500 m	38	42	0.85	
Less than 2000 m	36	38	0.80	
Less than 2500 m	34	35	0.75	
Less than 3000 m	32	32	0.70	

- 15) In locations where strong impacts or vibrations occur
- 16) In locations where a massive force strong enough to deform the product is applied or the weight from a heavy object is applied
- 17) In locations where there is not sufficient space for maintenance

2. Install in an environment where the unit will not come into direct contact with rain or snow.

These models are for indoor use only.

Do not install outdoors where rain or snow may fall on them.

3. Conduct ventilation and cooling to discharge heat. (Air-cooled refrigeration)

The heat which is cooled down through air-cooled condenser is discharged.

When using in a room which is shut tightly, ambient temperature will exceed the specification range stipulated in this catalog, which will activate the safety detector and stop the operation. In order to avoid this situation, discharge the heat outside of a room by ventilation or cooling facilities.

4. The product is not designed for clean room usage. It generates particles internally.



Be sure to read this before handling the products. Refer to page 513 for safety instructions and pages 514 to 517 for temperature control equipment precautions.

Mounting/Installation

MWarning

1. Do not use the product outdoors.

2. Do not place heavy objects on top of this product, or step on it. The external panel can be deformed and danger can result.

ACaution

- 1. Install on a rigid floor which can withstand this product's weight.
- 2. When installing without the casters, use the adjuster feet, etc. to raise the chiller to the following heights or more.


This product cannot be directly installed on the floor as some screws come out from the bottom of the product. • HRS012 to 030 10 mm

• HRS040 to 060 15 mm

3. Refer to the operation manual for this product, and secure an installation space that is necessary for the maintenance and ventilation.

<Air-cooled refrigeration>

- The air-cooled type product exhausts heat using the fan that is mounted to the product. If the product is operated with insufficient ventilation, ambient temperature may exceed 40°C*1, and this will affect the performance and life of the product. To prevent this ensure that suitable ventilation is available (see below).
 - *1 When option G, high-temperature environment specification, is selected: 45°C
- 2. For installation indoors, ventilation ports and a ventilation fan should be equipped as needed.



When option G, high-temperature environment specification, is selected: HRS030/HRS040/HRS050/HRS060 (A ventilation space is required since the ventilation slots are provided on the sides of the product.)

<Heat radiation amount/Required ventilation rate>

	Lines and the state	Required ventilation rate [m ³ /min]		
	Heat radiation	I	`	
Model	amount	Differential temp. of 3°C between inside	Differential temp. of 6°C between inside	
	[kW]	and outside of installation area	and outside of installation area	
HRS012-A	Approx. 2	40	20	
HRS018-A	Approx. 4	70	40	
HRS024-A	Approx. 5	90	50	
HRS030-A	Approx. 6	100	60	
HRS040-A	Approx. 8	120	70	
HRS050-A	Approx. 10	140	70	
HRS060-A	Approx. 10	140	70	

Piping

▲ Caution

1. Regarding the circulating fluid pipings, consider carefully the suitability for shutoff pressure, temperature and circulating fluid.

If the operating performance is not sufficient, the pipings may burst during operation. Also, the use of corrosive materials such as aluminum or iron for fluid contact parts, such as piping, may not only lead to clogging or leakage in the circulating fluid and facility water circuits but also refrigerant leakage and other unexpected problems. Provide protection against corrosion when you use the product.

- **2. Select the piping port size which can exceed the rated flow.** For the rated flow, refer to the pump capacity table.
- 3. When tightening at the circulating fluid inlet and outlet, drain port or overflow port of this product, use a pipe wrench to clamp the connection ports.
- 4. For the circulating fluid piping connection, install a drain pan and wastewater collection pit just in case the circulating fluid may leak.
- 5. This product series is constant-temperature fluid circulating machines with built-in tanks.

Do not install equipment on your system side such as pumps that forcibly return the circulating fluid to the unit. Also, if you attach an external tank that is open to the air, it may become impossible to circulate the circulating fluid. Proceed with caution.

Electrical Wiring


\land Warning

1. Grounding should never be connected to a water line, gas line or lightning rod.

▲Caution

- 1. Communication cable should be prepared by the user.
- 2. Provide a stable power supply which is not affected by surge or distortion.

If the voltage increase ratio (dV/dt) at the zero cross should exceed 40 V/200 $\mu sec.,$ it may result in malfunction.





Be sure to read this before handling the products. Refer to page 513 for safety instructions and pages 514 to 517 for temperature control equipment precautions.

Circulating Fluid

A Caution

1. Avoid oil or other foreign matter entering the circulating fluid.

2. When water is used as a circulating fluid, use tap water that conforms to the appropriate water quality standards. Use tap water that conforms to the standards shown below (including water used for dilution of ethylene glycol aqueous solution).

Tap Water (as a Circulating Fluid) Quality Standards

The Japan Refrigeration and Air Conditioning Industry Association

	RA GL-02-1994 Cooling water system – Circulation type – Make-up water				
				Influence	
	Item	Unit	Unit Standard value		Scale generation
	pH (at 25°C)	_	6.0 to 8.0	0	0
F	Electric conductivity (25°C)	[µS/cm]	100*1 to 300*1	0	0
item	Chloride ion (CI-)	[mg/L]	50 or less	0	
	Sulfuric acid ion (SO42-)	[mg/L]	50 or less	0	
da	Acid consumption amount (at pH4.8)	[mg/L]	50 or less		0
Standard	Total hardness	[mg/L]	70 or less		0
S	Calcium hardness (CaCO ₃)	[mg/L]	50 or less		0
	Ionic state silica (SiO ₂)	[mg/L]	30 or less		0
E	Iron (Fe)	[mg/L]	0.3 or less	0	0
item	Copper (Cu)	[mg/L]	0.1 or less	0	
e G	Sulfide ion (S2 ⁻)	[mg/L]	Should not be detected.	0	
Reference	Ammonium ion (NH ₄ +)	[mg/L]	0.1 or less	0	
efei	Residual chlorine (CI)	[mg/L]	0.3 or less	0	
ď	Free carbon (CO ₂)	[mg/L]	4.0 or less	Ó	

*1 In the case of [M Ω ·cm], it will be 0.003 to 0.01.

• O: Factors that have an effect on corrosion or scale generation

• Even if the water quality standards are met, complete prevention of corrosion is not guaranteed.

- 3. Use an ethylene glycol aqueous solution that does not contain additives such as preservatives.
- 4. When using ethylene glycol aqueous solution, maintain a maximum concentration of 15%.

Overly high concentrations can cause a pump overload. Low concentrations, however, can lead to freezing when circulating fluid temperature is 10°C or lower and cause the thermo-chiller to break down.

5. A magnet pump or mechanical seal pump is used as the circulating pump for the circulating fluid.

It is particularly impossible to use liquid including metallic powders such as iron powder.

6. The circulating fluids listed below have been tested for thermo-chiller compatibility.

No.	Fluid	Manufacturer	Concentration
4	Dowcal [™] 100 Heat	wcal [™] 100 Heat The Dow Chemical	
1	Transfer Fluid	Company	water
2	ControXid 1642	Oelheld GmbH	Ready to use
3	Hexid A4	Applied Thermal Control Limited	Ready to use
4	Coolflow IGE	Hydratech Division of Liquitherm Technologies Group Ltd	Dilute to 25% in water
5	NALCO [®] CCL105	Nalco Water, an Ecolab Company	Ready to use

 The chiller cooling capacity and pump capacity performance may change with using the fluids listed. Customers should verify the performances with the fluid and decide to use the fluid.

- Check the compatibility with the piping and the wetted parts of the customer's equipment before use.
 Check with the circulating fluid manufacturer for the following.
- 1) Countries and regions where it can be obtained and used
 3) Safety data sheets

 2) Handling and maintenance
 4) Specifications and physical properties
- Concentration has to be value listed or less. Overly high concentrations can cause a pump overload. Low concentrations, however, can lead to freezing when circulating fluid temperature is 10°C or lower and cause the thermo-chiller to break down.
- Using the fluid listed for a long time, the chiller heat exchanger performance may be reduced due to
 additive deposits. It is recommended to regularly flush the inside of the piping and chiller with clean water.
- In the case of a mechanical seal pump, additive deposits may appear on the outside, it is not a malfunction.

Facility Water Supply

Warning

<Water-cooled refrigeration>

1. The water-cooled refrigeration type thermo-chiller radiates heat to the facility water. Prepare the facility water system that satisfies the heat radiation and the facility water specifications below.

■ Required facility water system

<Heat radiation amount/Facility water specifications>

Model	Heat radiation [kW]	Facility water specifications
HRS012-WD-D	Approx. 2	
HRS018-W□-□	Approx. 4	
HRS024-W□-20	Approx. 5	Refer to
HRS030-W□-20	Approx. 6	"Facility water system"
HRS040-W□-20	Approx. 8	in the specifications.
HRS050-W□-20	Approx. 10	
HRS060-W□-20	Approx. 12	

2. When using tap water as facility water, use tap water that conforms to the appropriate water quality standards. Use tap water that conforms to the standards shown below. If the water quality standards are not met, clogging or leakage in the facility water piping, or other problems such as refrigerant leakage, etc., may result.

<Tap Water (as a Facility Water) Quality Standards>

The Japan Refrigeration and Air Conditioning Industry Association JRA GL-02-1994 "Cooling water system – Circulation type – Circulating water"

	Item	Unit	Standard value	Influence	
	Item	Unit Standard value		Corrosion	Scale generation
	pH (at 25°C)	—	6.5 to 8.2	0	0
	Electric conductivity (25°C)	[µS/cm]	100*1 to 800*1	0	0
item	Chloride ion (CI-)	[mg/L]	200 or less	0	
	Sulfuric acid ion (SO ₄ ²⁻)	[mg/L]	200 or less	0	
Standard	Acid consumption amount (at pH4.8)	[mg/L]	100 or less		0
star	Total hardness	[mg/L]	200 or less		0
0	Calcium hardness (CaCO ₃)	[mg/L]	150 or less		0
	Ionic state silica (SiO ₂)	[mg/L]	50 or less		0
E	Iron (Fe)	[mg/L]	1.0 or less	0	0
item	Copper (Cu)	[mg/L]	0.3 or less	0	
Ce	Sulfide ion (S_2^-)	[mg/L]	Should not be detected.	0	
eference	Ammonium ion (NH ₄ +)	[mg/L]	1.0 or less	0	
efe	Residual chlorine (CI)	[mg/L]	0.3 or less	Ó	
ũ	Free carbon (CO ₂)	[mg/L]	4.0 or less	Ó	

*1 In the case of [M Ω ·cm], it will be 0.001 to 0.01.

• O: Factors that have an effect on corrosion or scale generation

• Even if the water quality standards are met, complete prevention of corrosion is not guaranteed.

• We recommend to use the filter kit, FQ1011N-04-T020-B-X61, when you do not know the quality of circulating fluid to prevent leakage and other issues.

3. Supply pressure of 0.5 MPa or less.

If the supply pressure is high, it will cause water leakage.

4. Be sure to prepare your utilities so that the pressure of the thermo-chiller facility water outlet is at 0 MPa (atmospheric pressure) or more.

If the facility water outlet pressure becomes negative, the internal facility water piping may collapse, and proper flow control of facility water will be impossible.

Using deionized water as facility water may cause problems such as clogging in the piping due to metal ion.

5. Do not use fluid that includes metallic powders and other foreign materials.

It can cause issues: clogging of the circulating fluid circuit or leakage.

SMC

HRS

HED

Technical Data



Be sure to read this before handling the products. Refer to page 513 for safety instructions and pages 514 to 517 for temperature control equipment precautions.

Operation

\land Warning

1. Confirmation before operation

1) The fluid level of a tank should be within the specified range of "HIGH" and "LOW."

When exceeding the specified level, the circulating fluid will overflow.

2) Remove the air.

Conduct a trial operation, looking at the fluid level.

Since the fluid level will go down when the air is removed from the user's piping system, supply water once again when the fluid level is reduced. When there is no reduction in the fluid level, the job of removing the air is completed. Pump can be operated independently.

2. Confirmation during operation

· Check the circulating fluid temperature.

The operating temperature range of the circulating fluid is between 5 and 40° C.

When the amount of heat generated from the user's equipment is greater than the product's capability, the circulating fluid temperature may exceed this range. Use caution regarding this matter.

3. Emergency stop method

• When an abnormality is confirmed, stop the machine immediately. After pushing the [OFF] switch, be sure to turn off the power switch.

Operation Restart Time/Operation and Suspension Frequency

A Caution

- 1. Wait five minutes or more before restarting operation after it has been stopped. If the operation is restarted within five minutes, the protection circuit may activate and the operation may not start properly.
- 2. Operation and suspension frequency should not exceed 10 times per day. Frequently switching between operation and suspension may result in the malfunction of the refrigeration circuit.

Protection Circuit

▲ Caution

- 1. If operating in the below conditions, the protection circuit will activate and an operation may not be performed or will stop.
 - \bullet Power supply voltage is not within the rated voltage range of $\pm 10\%.$
 - In case the water level inside the tank is reduced abnormally.
 - Circulating fluid temperature is too high.
 - Compared to the cooling capacity, the heat generation amount of the user's equipment is too high.
 - Ambient temperature is too high. (40°C or more)
 - Refrigerant pressure is too high.
 - Ventilation hole is clogged with dust or dirt.

Trademark Information

Modbus® is a registered trademark of Schneider Electric, licensed to the Modbus Organization, Inc.

▲ Caution

<Periodical inspection every one month>

1. Clean the ventilation hole.

If the dustproof filter becomes clogged with dust or debris, a decline in cooling performance can result. In order to avoid deforming or damaging the dustproof filter, clean it with a long-haired brush or air gun.

<Periodical inspection every three months>

1. Inspect the circulating fluid.

- 1) When using tap water
 - · Replacement of tap water

Failure to replace the tap water can lead to the development of bacteria and algae. Replace it regularly according to your usage conditions.

Tank cleaning

Consider whether dirt, slime, or foreign matter may be present in the circulating fluid inside the tank, and carry out regular cleanings of the tank.

 When using ethylene glycol aqueous solution Use a concentration meter to confirm that the concentration does not exceed 15%.

Dilute or add as needed to adjust the concentration.

<Periodical inspection during the winter season>

1. Make water-removal arrangements beforehand.

If there is a risk of the circulating fluid freezing when the product is stopped, release the circulating fluid in advance.

2. Contact a professional.

For additional methods to prevent freezing (such as commercially available tape heaters, etc.), contact a professional for advice.

Refrigerant with GWP reference

	Global warming potential (GWP)			
Refrigerant	Regulation (EU) No 517/2014 (Based on the IPCC AR4)	Revised Fluorocarbons Recovery and Destruction Law (Japanese law)		
R134a	1,430	1,430		
R404A	3,922	3,920		
R407C	1,774	1,770		
R410A	2,088	2,090		

* This product is hermetically sealed and contains fluorinated greenhouse gases (HFC). When this product is sold on the market in the EU after January 1, 2017, it needs to be compliant with the quota system of the F-Gas Regulation in the EU.

* See specification table for refrigerant used in the product.

