Electric Slide Tables (6 PA) US ROHS



LES/LESH Series

Step Motor (Servo/24 VDC) Servo Motor (24 VDC)

- Reduced cycle time
- Positioning repeatability: ±0.05 mm

■ Max. pushing force: 180 N

Max. acceleration/deceleration: 5000 mm/s²

Max. speed: 400 mm/s

Compact Type LES Series

Size: 8, 16, 25 ▶Page 314

Compared with the LESH, Workpiece mounting surface height: Reduced by up to 12%





46 mm




Compact type LES16D

LESH16D









In-line motor type/D type



Size: 8, 16, 25 ▶Page 340

High Rigidity Type LESH Series



Deflection: 0.016 mm*

* LESH16-50 Load: 25 N













▶Step data input LECP6/LECA6 Series

• 64 points positioning · Input using controller setting kit or teaching



Step Motor (Servo/24 VDC) Servo Motor (24 VDC) Controller/Driver

▶CC-Link direct input type **LECPMJ** Series

► EtherCAT®/EtherNet/IP™/ PROFINET/DeviceNet™/ IO-Link direct input type JXCE1/91/P1/D1/L1 Series * Not applicable to CE.



▶Pulse input LECPA Series



▶Page 547


Compact Type LES Series



Increased by up to 50%*

- * By reducing weight of the moving parts
- * Compared with the LESH16

Model	Vertical work load [kg]
LES16	3.0
LESH16	2.0





Reduced by up to 29%

Model	Weight [kg]	Reduction amount
LES16D-100	1.20	Reduced by
LESH16D-100	1.70	0.50 kg

Max. pushing force: 180 N

Positioning repeatability: ±0.05 mm

Possible to reduce cycle time
 Max. acceleration/deceleration: 5000 mm/s²

Max. speed: 400 mm/s

• 2 types of motors selectable: Step motor (Servo/24 VDC), Servo motor (24 VDC)






High Rigidity Type LESH Series



(High rigidity) Deflection: 0.016 mm* * LESH16-50 Load: 25 N

Integration of the guide rail and the table Uses a circulating linear guide.



Compact, Space-saving


For LESH8 B/L 50 mm stroke




- Reduced by 61% in volume*
 - * Compared with the LESH16-50/LXSH-50
 - * For R/L type
- Motor integrated into the body (Built-in motor

2 types of motors selectable

- Step motor (Servo/24 VDC) Ideal for transfer of high load at a low speed and pushing operation
- Servo motor (24 VDC) Stable at high speed and silent operation






Non-magnetizing lock mechanism (Option)

Prevents workpieces from dropping (holding)


Adjustment operation possible when power OFF





Symmetrical Type/L Type

The locations of the table and cable are opposite those of the basic type (R type), expanding design applications.











In-line Motor Type/D Type

Width dimension shortened by up to 45%





A Dim	ension	[mm]
Size	D type	R/L type
8	32	58.5
16	45	72.5
25	61	106







Step Motor (Servo/24 VDC) Servo Motor (24 VDC)

Electric Slide Table/Compact Type LES Series



Model Selection ·····	·Page 314
How to Order ····	Pages 324, 325-1
Specifications	· Page 326
Construction	· Page 328
Dimensions ····	Page 330

Step Motor (Servo/24 VDC) Servo Motor (24 VDC)

Electric Slide Table/High Rigidity Type LESH Series



Model Selection Page 340 How to Order ------ Pages 350, 351-1 Specifications Page 352 Construction Page 354 Specific Product Precautions Page 366

Step Motor (Servo/24 VDC)/Servo Motor (24 VDC) Controller



Step Data Input Type/LECP6/LECA6 Series ----- Page 560 Controller Setting Kit/LEC-W2 Page 569 Teaching Box/LEC-T1 Page 570 CC-Link Direct Input Type/LECPMJ Series ----- Page 600 Controller Setting Kit/LEC-W2 Page 603-2 Teaching Box/LEC-T1 Page 603-3 EtherCAT®/EtherNet/IP™/PROFINET/DeviceNet™/IO-Link Direct Input Type/JXCE1/91/P1/D1/L1 Series ----- Page 603-5 Controller Setting Kit/LEC-W2 ----- Page 603-10 Teaching Box/*LEC-T1* Page 605 Gateway Unit/LEC-G Series Page 572 Programless Controller/LECP1 Series ------ Page 576 Controller Setting Kit/LEC-W2 Page 597 Teaching Box/LEC-T1 Page 598


4-Axis Step Motor Controller (Servo/24 VDC)




Parallel I/O/JXC73/83 Series ····· Page 606-1 EtherNet/IP™ Type/JXC93 Series ·····Page 606-1

Slide Tables

Compact Type LES Series



High Rigidity Type LESH Series



Electric Slide Table/Compact Type

LES Series

Model Selection 1

LES Series Pages 324, 325-1

Selection Procedure For the high rigidity type LESH series, refer to page 340

Calculation example)

T1 to T4 can be calculated as follows.

 $= \frac{50 - 0.5 \cdot 220 \cdot (0.04 + 0.04)}{}$

220

Therefore, the cycle time can be

= 0.04 + 0.19 + 0.04 + 0.15

T1 = V/a1 = 220/5000 = 0.04 [s],

T3 = V/a2 = 220/5000 = 0.04 [s]

 $T2 = \frac{L - 0.5 \cdot V \cdot (T1 + T3)}{L - 0.5 \cdot V \cdot (T1 + T3)}$

= 0.19 [s]

obtained as follows.

T = T1 + T2 + T3 + T4

T4 = 0.15 [s]

= 0.42 [s]



Step 1 Check the work load-speed.



Step 2 Check the cycle time.



Step 3 Check the allowable moment.

Selection Example -

Step 1 Check the work load-speed. <Speed-Work load graph> (Page 315) Select the target model based on the workpiece mass and speed with reference to the <Speed-Work load graph>.

Selection example) The LES16 J-50 is temporarily selected based on the graph shown on the right side.

Step 2 Check the cycle time.

It is possible to obtain an approximate cycle time by using method 1, but if a more detailed cycle time is required, use method 2.

Method 1: Check the cycle time graph. (Page 316)

Method 2: Calculation <Speed-Work load graph> (Page 315)

Calculate the cycle time using the following calculation method.

Cycle time:

T can be found from the following equation.

• T1: Acceleration time and T3: Deceleration time can be obtained by the following equation.

• T2: Constant speed time can be found from the following equation.

$$T2 = \frac{L - 0.5 \cdot V \cdot (T1 + T3)}{V} [s]$$


• T4: Settling time varies depending on the conditions such as motor types, load and in position of the step data. Therefore, calculate the settling time with reference to the following value.

Operating conditions

- Workpiece mass: 1 [kg] Workpiece mounting condition: •Speed: 220 [mm/s]
- Mounting orientation: Vertical
- Stroke: 50 [mm]
- Acceleration/Deceleration: 5000 [mm/s²]
- Cycle time: 0.5 seconds




LES16□/Step Motor Vertical



<Speed-Work load graph>


LES16□/Step Motor



<Cycle time> LES16/Pitching

Step 3 Check the allowable moment. <Static allowable moment> (Page 316) <Dvnamic allowable moment> (Pages 317, 318)

Confirm the moment that applies to the actuator is within the allowable range for both static and dynamic conditions.



<Dvnamic allowable moment>

Based on the above calculation result, the LES16□J-50 is selected.





Speed-Work Load Graph (Guide)

Step Motor (Servo/24 VDC)

* The following graph shows the values when moving force is 100%.

LES8□







Servo Motor (24 VDC)


* The following graph shows the values when moving force is 250%.


LES8□A






LES16







LES16□A






LES25□






LES25^RA





Cycle Time (Guide)



Operating Conditions

Acceleration/Deceleration: 5000 mm/s²

In position: 0.5 mm


Static Allowable Moment

Mode	el	LES8	LES16	LES25
Pitching	[N·m]	2	4.8	14.1
Yawing	[N·m]	2	4.8	14.1
Rolling	[N·m]	0.8	1.8	4.8




Dynamic Allowable Moment

This graph shows the amount of allowable overhang (guide unit) when the center of gravity of the workpiece overhangs in one direction. When selecting the overhang, refer to "Calculation of Guide Load Factor" or the Electric Actuator Selection Software for confirmation, http://www.smcworld.com



Dynamic Allowable Moment

This graph shows the amount of allowable overhang (guide unit) when the center of gravity of the workpiece overhangs in one direction. When selecting the overhang, refer to "Calculation of Guide Load Factor" or the Electric Actuator Selection Software for confirmation, thttp://www.smcword.com



Calculation of Guide Load Factor

1. Decide operating conditions

Model: LES

Size: 8/16/25

Mounting orientation: Horizontal/Bottom/Wall/Vertical

Acceleration [mm/s²]: **a**Work load [kg]: **m**

cal Work load center position [mm]: Xc/Yc/Zc

- 2. Select the target graph with reference to the model, size and mounting orientation.
- 3. Based on the acceleration and work load, obtain the overhang [mm]: Lx/Ly/Lz from the graph.
- 4. Calculate the load factor for each direction
- α **x** = **Xc/Lx**, α **y** = **Yc/Ly**, α **z** = **Zc/Lz** 5. Confirm the total of α **x**, α **y** and α **z** is 1 or less.

 $\alpha x + \alpha y + \alpha z \le 1$

When 1 is exceeded, please consider a reduction of acceleration and work load, or a change of the work load center position and series.

Evample

1. Operating conditions

Model: LES

Size: 8


Mounting orientation: Horizontal


Acceleration [mm/s²]: 5000


Work load [kg]: 0.6

Work load center position [mm]: Xc = 50, Yc = 30, Zc = 60

2. Select three graphs from the top of the left side first row on page 317.







--- Mounting orientation


- 3. Lx = 220 mm, Ly = 135 mm, Lz = 250 mm
- 4. The load factor for each direction can be obtained as follows.

 $\alpha x = 50/220 = 0.23$

 $\alpha y = 30/135 = 0.22$

 $\alpha z = 60/250 = 0.24$

5. $\alpha x + \alpha y + \alpha z = 0.69 \le 1$





Electric Slide Table/Compact Type


LES Series

Model Selection 2

LES Series Pages 324, 325-1

Selection Procedure For the high rigidity type LESH series, refer to page 346.

Step 1 Check the required force.





[ka]

Selection Example

Operating conditions

- Pushing force: 90 [N]
- · Mounting orientation: Vertical upward
- •Workpiece mass: 1 [kg] • Speed: 100 [mm/s]
- Pushing time + Operation (A): 1.5 seconds
- · All cycle time (B): 6 seconds
- •Stroke: 100 [mm]



Step 1 Check the required force.

Calculate the approximate required force for pushing operation. Selection example) • Pushing force: 90 [N]

- Workpiece mass: 1 [kg]
- Therefore, the approximate required force can be obtained as 90 + 10 = 100 [N].

Select the target model based on the approximate required force with reference to the specifications (Pages 326 and 327). Selection example) Based on the specifications,

- Approximate required force: 100 [N]
- Speed: 100 [mm/s]

Therefore, the LES25□ is temporarily selected.

Then, calculate the required force for pushing operation. If the mounting position is vertical upward, add the actuator table weight.

Selection example) Based on the <Table weight>,

- LES25

 table weight: 0.5 [kg] Therefore, the required force can be
 - obtained as 100 + 5 = 105 [N].

Step 2 Check the set value of pushing force. <Set value of pushing force-Force graph> (Page 321)

Select the target model based on the required force with reference to the <Set value of pushing force-Force graph>, and confirm the set value of pushing force.

Selection example) Based on the graph shown on the right side,

- Required force: 105 [N]
- Therefore, the LES25 K is temporarily selected.
- This set value of pushing force is 40 [%].

Step 3 Check the duty ratio.

Confirm the allowable duty ratio based on the set value of pushing force with reference to the <Allowable duty ratio>. Selection example) Based on the <Allowable duty ratio>,

• Set value of pushing force: 40 [%] Therefore, the allowable duty ratio can be obtained as 30 [%].

Calculate the duty ratio for operating conditions, and confirm it does not exceed the allowable duty ratio.

Selection example) . Pushing time + Operation (A): 1.5 seconds

· All cycle time (B): 6 seconds


Therefore, the duty ratio can be obtained as $1.5/6 \times 100 = 25$ [%], and this is the allowable range.

Based on the above calculation result, the LES25 K-100 is selected. For allowable moment, the selection procedure is the same as the positioning control.

Table Weight

	J. 9					1.19
Model		Stroke [mm]				
iviodei	30	50	75	100	125	150
LES8	0.06	0.08	0.10	_	_	_
LES16	0.10	0.13	0.18	0.20	_	_
LES25	0.25	0.30	0.36	0.50	0.55	0.59

* If the mounting position is vertical upward, add the table weight.



<Set value of pushing force-Force graph>

Allowable Duty Ratio


Step Motor (Servo/24 VDC)

Set value of pushing force (%)	Duty ratio (%)	Continuous pushing time (minute)
30	_	_
50 or less	30 or less	5 or less
70 or less	20 or less	3 or less

Servo Motor (24 VDC)

Set value of pushing force (%)	Duty ratio (%)	Continuous pushing time (minute)
50	_	_
75 or less	30 or less	5 or less
100 or less	20 or less	3 or less

* The pushing force of the LES8 A is up to 75%.







Set Value of Pushing Force-Force Gragh

Step Motor (Servo/24 VDC)


LES8□



LES16□




LES25□




Servo Motor (24 VDC)


LES8□A



LES16□A



LES25^RA





* Set values for the controller.






Table Accuracy





Model	LES8	LES16	LES25
B side parallelism to A side 0.4 mm			
B side traveling parallelism to A side	Refer to Graph 1.		1.
C side perpendicularity to A side	0.2 mm		
M dimension tolerance	±0.3 mm		
W dimension tolerance	±0.2 mm		

Graph 1 B side traveling parallelism to A side






Table Deflection (Reference Value)


* These values are initial guideline values.

Pitching moment


Table displacement due to pitch moment load Table displacement when loads are applied to the section marked with the arrow with the slide table stuck out.




LES8



LES16



LES25




Yawing moment


Table displacement due to yaw moment load Table displacement when loads are applied to the section marked with the arrow with the slide table stuck out.




LES8



LES₁₆




LES25




Rolling moment


Table displacement due to roll moment load Table displacement of section A when loads are applied to the section F with the slide table retracted.




LES8



LES₁₆



LES25



Electric Slide Table/ Compact Type

LES Series LES8, 16, 25








Basic type (R type)

Symmetrical type (L type) In-line motor type (D type)




2 Motor mounting position

Symmetrical type/L type Table

In-line motor type/D type

Basic type/R type



1 Size

8
16
25

4 Lead [mm]

Symbol	LES8	LES16	LES25
J	8	10	16
K	4	5	8

5 Stroke [mm]

• • • • • • • • • • • • • • • • • • • •			
Stroke	None		
Stroke	Size	Applicable stroke	
30 to 75	8	30*2, 50*2, 75	
30 to 100	16	30*2, 50*2, 75, 100	
30 to 150	25	30*2, 50, 75, 100, 125, 150	

6 Motor option

	O 1110101 Option					
Nil	Without option					
В	With lock					

	7 - 1
Nil	Without option
S	Dust-protected*3

Motor type

Symbol	Туре	Compatible controller/driver	
Nil	Step motor (Servo/24 VDC)	LECP6 JXCE1 LECP1 JXC91 LECPA JXCP1 LECPMJ JXCD1 JXCL1	
A	Servo motor*1 (24 VDC)	LECA6	

Body option


Nil	Without option
S	Dust-protected*3

Actuator cable type/length*6

Standard cable [m]			Robotic	cable		[m]
Nil	None	ĺ	R1	1.5	RA	10*5
S1	1.5*8	ĺ	R3	3	RB	15*5
S3	3*8	ſ	R5	5	RC	20*5
S5	5*8	[R8	8*5		

8 Mounting*4

Symbol	Mounting	R type L type	D type
Nil	Without side holder	•	•
Н	With side holder (4 pcs.)	_	•









Nil	Without controller/driver				
6N	LECP6/LECA6	NPN			
6P	(Step data input type)	PNP			
1N	LECP1*8	NPN			
1P	(Programless type)	PNP			
MJ	LECPMJ*8 *9 (CC-Link direct input type)	_			
AN	LECPA*8 *10	NPN			
AP	(Pulse input type)	PNP			

I/O cable length*11, Communication plug

Nil	Without cable (Without communication plug connector)*13
1	1.5 m
3	3 m*12
5	5 m*12
S	Straight type communication plug connector*13
Т	T-branch type communication plug connector*13




Controller/Driver mounting				
Nil	Screw mounting			
D	DIN rail mounting*14			

JXC Series (For details, refer to

Without controller





Communication plug connector for DeviceNet™*15

Nil Without plug connector					
S	Straight type				
Т	T-branch type				

- IO-Link *1 LES25DA is not available.
- *2 R/L type with lock is not available.
- *3 For R/L type (IP5X equivalent), a scraper is mounted on the rod cover, and gaskets are mounted on both the end covers. For D type, a scraper is mounted on the rod cover.
- *4 Refer to page 339 for details.
- *5 Produced upon receipt of order (Robotic cable only)
- *6 The standard cable should only be used on fixed parts.
- For use on moving parts, select the robotic cable. *7 For details about controller/driver and compatible motor, refer to the
- compatible controller/driver on the next page.
- *8 Only available for the motor type "Step motor."
- *9 Not applicable to CE.

_Caution

[CE-compliant products]

1) EMC compliance was tested by combining the electric actuator LES series and the controller LEC/JXC series.

The EMC depends on the configuration of the customer's control panel and the relationship with other electrical equipment and wiring. Therefore, conformity to the EMC directive cannot be certified for SMC components incorporated into the customer's equipment under actual operating conditions. As a result, it is necessary for the customer to verify conformity to the EMC directive for the machinery and equipment as a whole

- 2 For the servo motor (24 VDC) specification, EMC compliance was tested by installing a noise filter set (LEC-NFA). Refer to page 568 for the noise filter set. Refer to the LECA series Operation Manual for installation.
- 3 CC-Link direct input type (LECPMJ) is not CE-compliant.

[UL-compliant products]

When conformity to UL is required, the electric actuator and controller/ driver should be used with a UL1310 Class 2 power supply.


- *10 When pulse signals are open collector, order the current limiting resistor (LEC-PA-R-\(\sigma\)) on page 596 separately.
- *11 When "Without controller/driver" is selected for controller/driver types, I/O cable cannot be selected. Refer to page 568 (For LECP6/LECA6), page 582 (For LECP1) or page 596 (For LECPA) if I/O cable is required.
- *12 When "Pulse input type" is selected for controller/driver types, pulse input usable only with differential. Only 1.5 m cables usable with open collector.
- *13 For the LECPMJ, only "Nil", "S" and "T" are selectable since I/O cable is not included
- *14 DIN rail is not included. Order it separately.
- *15 Select "Nil" for anything other than DeviceNet™.

The actuator and controller/driver are sold as a package.

Confirm that the combination of the controller/driver and the actuator is correct.

<Check the following before use.>

- 1) Check the actuator label for model number. This matches the controller/driver.
- 2 Check Parallel I/O configuration matches (NPN or PNP).



* Refer to the Operation Manual for using the products. Please download it via our website, https://www.smcworld.com





Compatible Controller/Driver

IVC Corrier

© 325-1

LEC□ Series Step data input type Step data input type **CC-Link direct** Programless type Pulse input type input type Type Series LECP6 LECA6 LECPMJ LECP1 LECPA Capable of setting up Value (Step data) input operation (step data) without Operation by pulse signals Features CC-Link direct input Standard controller using a PC or teaching box Step motor Servo motor Step motor Compatible motor (Servo/24 VDC) (24 VDC) (Servo/24 VDC) Maximum number of step data 64 points 14 points Power supply voltage 24 VDC Reference page Page 560 Page 560 Page 600 Page 576 Page 590

JXC Ser	ies				
Туре	EtherCAT® direct input type	EtherNet/IPTM direct input type	PROFINET direct input type	DeviceNet™ direct input type	IO-Link direct input type
Series	JXCE1	JXC91	JXCP1	JXCD1	JXCL1
Features	EtherCAT® direct input	EtherNet/IP™ direct input	PROFINET direct input	DeviceNet™ direct input	IO-Link direct input
Compatible motor	Step motor				
Maximum number of step data			64 points		
Power supply voltage			24 VDC		
Reference page			Page 603-5		



Specifications

Step Motor (Servo/24 VDC)

Model		LES8□		LES16□		LES25□		
Stroke [mm]	Stroke [mm]		30, 50, 75 30, 50, 75, 100		30, 50, 75, 100, 125, 150			
Work load [kg] Note 1	Horizontal	1		3	3		5	
work load [kg]	Vertical	0.5	0.25	3	1.5	5	2.5	
ν Pushing force 30 to 3		6 to 15	4 to 10	23.5 to 55	15 to 35	77 to 180	43 to 100	
5 Speed [mm/s] Note	Speed [mm/s] Note 1) 3)		20 to 400	10 to 200	20 to 400	10 to 200	20 to 400	
Pushing speed [n	nm/s]	10 to 20	20	10 to 20	20	10 to 20	20	
Max. acceleration/dec	eleration [mm/s ²]			50	00			
Speed [mm/s] Note Speed [mm/s] Note Pushing speed [n Max. acceleration/decr Positioning repea	tability [mm]			±0.	.05			
	Note 4)			0.3 o	r less			
Screw lead [mm]		4	8	5	10	8	16	
Impact/Vibration resist	tance [m/s²] Note 5)			50/	/20			
Actuation type	Actuation type		Slide screw + Belt (R/L type), Slide screw (D type)					
Guide type	Guide type		Linear guide (Circulating type)					
Operating temperat	Operating temperature range [°C]		5 to 40					
Operating humidity	Operating humidity range [%RH]		90 or less (No condensation)					
Motor size	Motor size		□20 □28 □42				42	
Motor size Motor type Encoder Rated voltage [V]		Step motor (Servo/24 VDC)						
<u>≅</u> Encoder	Encoder		Incremental A/B phase (800 pulse/rotation)					
Rated voltage [V]		24 VDC ±10%						
	ion [W] Note 6)	18		69		45		
Standby power consumption w	hen operating [W] Note 7)	7	7	1	5	13		
maxi motantanovao ponor e	onsumption [W] Note 8)	3	5	6	9	67		
Type Holding force [N] Power consumption				Non-magn	etizing lock			
ਤਿੱਲ Holding force [N]		24	2.5	300	48	500	77	
Power consumption	Power consumption [W] Note 10)		5	2.	.9		5	
ិន្ត Rated voltage [V]				24 VDC	C ±10%			

- Note 1) Speed changes according to the work load. Check "Speed-Work Load Graph (Guide)" on page 315.
- Note 2) Pushing force accuracy is ±20% (F.S.).
- Note 3) The speed and force may change depending on the cable length, load and mounting conditions. Furthermore, if the cable length exceeds 5 m, then it will decrease by up to 10% for each 5 m. (At 15 m: Reduced by up to 20%)
- Note 4) A reference value for correcting an error in reciprocal operation.
- Note 5) Vibration resistance: No malfunction occurred in a test ranging between 45 to 2000 Hz. Test was performed in both an axial direction and a perpendicular direction to the lead screw. (Test was performed with the actuator in the initial state.) Impact resistance: No malfunction occurred when the actuator was tested with a drop tester in both an axial direction and a perpendicular direction to the lead screw. (Test was performed with the actuator in the initial state.)
- Note 6) The power consumption (including the controller) is for when the actuator is operating.
- Note 7) The standby power consumption when operating (including the controller) is for when the actuator is stopped in the set position during the operation. Except during the pushing operation.
- Note 8) The maximum instantaneous power consumption (including the controller) is for when the actuator is operating. This value can be used for the selection of the power supply.
- Note 9) With lock only
- Note 10) For an actuator with lock, add the power consumption for the lock.

Specifications

Servo Motor (24 VDC)

Model			LES8□A		LES1	6□A	LES25 ^R A Note 1)		
	Stroke [mm]		30, 5	0, 75	30, 50,	75, 100	30, 50, 75, 100, 125, 150		
	Work load [kg]	Horizontal	1		3		5		
		Vertical	1	0.5	3	1.5	4	2	
s	Pushing force 50	to 100% [N] Note 2)	7.5 to 11	5 to 7.5	17.5 to 35	10 to 20	31 to 62	19 to 38	
6	Speed [mm/s]		1 to 200	1 to 400	1 to 200	1 to 400	1 to 200	1 to 400	
cat	Pushing speed	[mm/s]			1 to	20			
ij	Max. acceleration/d	eceleration [mm/s ²]			50	00			
specifications	Positioning rep	eatability [mm]			±0.	05			
	Lost motion [mm] Note 3)				0.3 o	rless			
atc	Screw lead [mn	n]	4	8	5	10	8	16	
Actuator	Impact/Vibration resistance [m/s ²] Note 4)		50/20						
٩	Actuation type		Slide screw + Belt (R/L type), Slide screw (D type)						
	Guide type		Linear guide (Circulating type)						
	Operating tempe	rature range [°C]	5 to 40						
	Operating humic	dity range [%RH]	90 or less (No condensation)						
S.	Motor size			20		28		42	
ecifications	Motor output [V	V]	10 30 36					6	
28	Motor type		Servo motor (24 VDC)						
Sci	Encoder (Angular di	splacement sensor)	Incremental A/B/Z phase (800 pulse/rotation)						
g	Rated voltage [•	24 VDC ±10%						
.2	Power consum		42		68		97		
Electric	Standby power consumption		8 (Horizontal)	/19 (Vertical)	9 (Horizontal)/23 (Vertical)		16 (Horizontal)/32 (Vertical)		
	Max. instantaneous pow	er consumption [W] Note 7)	71 102 111						
it	Туре				Non-magn	etizing lock			
cation	Holding force [24	2.5	300	48	500	77	
Pock	Power consumpti	ion [W] Note 9)	3.	5	2.	<u>-</u>	5	5	
ds	Rated voltage [V]			24 VDC	±10%			

Note 1) LES25DA is not available.

Note 2) The pushing force values for LES8□A is 50 to 75%. Pushing force accuracy is ±20% (F.S.).

Note 3) A reference value for correcting an error in reciprocal operation.

Note 4) Vibration resistance: No malfunction occurred in a test ranging between 45 to 2000 Hz. Test was performed in both an axial direction and a perpendicular direction to the lead screw. (Test was performed with the actuator in the initial state.) Impact resistance: No malfunction occurred when the actuator was tested with a drop tester in both an axial direction and a perpendicular direction to the lead screw. (Test was performed with the actuator in the initial state.)

Note 5) The power consumption (including the controller) is for when the actuator is operating.

Note 6) The standby power consumption when operating (including the controller) is for when the actuator is stopped in the set position during the operation. Except during the pushing operation.

Note 7) The maximum instantaneous power consumption (including the controller) is for when the actuator is operating. This value can be used for the selection of the power supply.

Note 8) With lock only

Note 9) For an actuator with lock, add the power consumption for the lock.


Weight

Step Motor (Servo/24 VDC), Servo Motor (24 VDC) Common

Step Motor (Servo/24 VDC), Servo Motor (24 VDC) Common [kg]													
				Witho	ut lock					With	lock		
Stroke [mm]		30	50	75	100	125	150	30	50	75	100	125	150
	LES8 ^R (A)	0.45	0.54	0.59	_	_	_	_	_	0.66	_	_	_
	LES16 ^R (A)	0.91	1.00	1.16	1.24	_	_	_	_	1.29	1.37	_	_
Model	LES25 ^R (A)	1.81	2.07	2.41	3.21	3.44	3.68	_	2.34	2.68	3.48	3.71	3.95
Wodei	LES8D(A)	0.40	0.52	0.58	_	_	_	0.47	0.59	0.65	_	_	_
	LES16D(A)	0.77	0.90	1.11	1.20	_	_	0.90	1.03	1.25	1.33	_	_
	LES25D	1.82	2.05	2.35	3.07	3.27	3.47	2.08	2.31	2.61	3.33	3.53	3.74



Construction: Basic Type/R Type, Symmetrical Type/L Type





В-В

Component Parts							
No.	Description	Material	Note				
1	Motor	_	_				
2	Body	Aluminum alloy	Anodized				
3	Table	Stainless steel	Heat treatment + Electroless nickel plating				
4	Guide block	Stainless steel	Heat treatment				
5	Lead screw	Stainless steel	Heat treatment + Specially treated				
6	End plate	Aluminum alloy	Anodized				
7	Pulley cover	Synthetic resin	_				
8	End cover	Synthetic resin	_				
9	Rod	Stainless steel	_				
		Structural steel	Electroless nickel plating				
10	Bearing stopper	Brass	Electroless nickel plating (LES25R/L□ only)				
11	Motor plate	Structural steel					
12	Socket	Structural steel	Electroless nickel plating				
13	Lead screw pulley	Aluminum alloy	_				
14	Motor pulley	Aluminum alloy	_				
15	Spacer	Stainless steel	LES25R/L□ only				
16	Origin stopper	Structural steel	Electroless nickel plating				
17	Bearing	_	_				
18	Belt	_	_				
19	Grommet	Synthetic resin	_				
20	Сар	SI	_				
21	Sim ring	Structural steel					

No.	Description	Material	Note
22	Stopper	Structural steel	_
23	Bushing	—	Dust-protected option only
24	Pulley gasket	NBR	Dust-protected option only
25	End gasket	NBR	Dust-protected option only
26	Scraper	NBR	Dust-protected option only
27	Cover	Synthetic resin	_
28	Return guide	Synthetic resin	_
29	Cover support	Stainless steel	_
30	Steel ball	Special steel	_
31	Lock	_	With lock only
31	Lock	_	With lock only


Replacement Parts/Belt


Size	Order no.	Note
LES8□	LE-D-1-1	Without manual override screw
LES16□	LE-D-1-2	_
LES25□	LE-D-1-3	_
LES25□A	LE-D-1-4	_
LES8□	LE-D-1-5	With manual override screw


Replacement Parts/Grease Pack

Applied portion	Order no.			
Guide unit	GR-S-010 (10 g) GR-S-020 (20 g)			

Construction: In-line Motor Type/D Type









Component Parts

No.	Description	Material	Note
1	Motor	_	_
2	Body	Aluminum alloy	Anodized
3	Table	Stainless steel	Heat treatment + Electroless nickel plating
4	Guide block	Stainless steel	Heat treatment
5	Lead screw	Stainless steel	Heat treatment + Specially treated
6	End plate	Aluminum alloy	Anodized
7	Motor flange	Aluminum alloy	Anodized
8	Stopper	Structural steel	_
9	Motor cover	Aluminum alloy	Anodized
10	End cover	Aluminum alloy	Anodized
11	Motor end cover	Aluminum alloy	Anodized
12	Rod	Stainless steel	_
		Structural steel	Electroless nickel plating
13	Bearing stopper	D	Electroless nickel plating
		Brass	(LES25D□ only)
14	Socket	Structural steel	Electroless nickel plating
15	Hub (Lead screw side)	Aluminum alloy	_
16	Hub (Motor side)	Aluminum alloy	_
17	Spacer	Stainless steel	LES25D□ only
18	Grommet	NBR	_
19	Spider	NBR	_
20	Cover	Synthetic resin	

No.	Description	Material	Note		
21	Return guide	Synthetic resin	_		
22	Cover support	Stainless steel	_		
23	Steel ball	Special steel	_		
24	Bearing	_	_		
25	Sim ring	Structural steel	_		
26	Masking tape	_	_		
27	Bushing	_	Dust-protected option only		
28	Scraper	NBR	Dust-protected option only		
29	Lock	_	With lock only		
30	Side holder	Aluminum alloy	Anodized		
	*				

Optional Parts/Side Holder

Model	Order no.
LES8D	LE-D-3-1
LES16D	LE-D-3-2
LES25D	LE-D-3-3

Replacement Parts/Grease Pack


Applied portion	Order no.
Guide unit	GR-S-010 (10 g) GR-S-020 (20 g)







Dimensions: Basic Type/R Type

LES8R







Note 1) Range within which the table can move when it returns to origin.

Make sure a workpiece mounted on the table does not interfere with the workpieces and facilities around the table.

Note 2) Position after return to origin.

Note 3) [] for when the direction of return to origin has changed.

Note 4) If workpiece retaining screws are too long, they can touch the guide block and cause a malfunction.

Use screws that are between the maximum and minimum screw-in depths in length.

Note 5) Secure the motor cable and lock cable so that the cables are not repeatedly bent.

	Connector	
	Step motor	Servo motor
Motor cable	20	24
Lock cable	07	15 15

With lock


Lock cable (ø3.5) Note 5)


Motor cable (2 x ø5) Note 5)


Dimensions							[mm]
Model	L	D	E	F	G	Н	J
LES8R	94.5	26	88.7	62.5	2	27	27
LES8R	137.5	46	131.7	105.5	3	29	58
LES8R75	162.5	50	156.7	130.5	4	30	60

Dimensions: Basic Type/R Type

LES16R







Note 1) Range within which the table can move when it returns to origin.

Make sure a workpiece mounted on the table does not interfere with the workpieces and facilities around the table.

Note 2) Position after return to origin.

Note 3) [] for when the direction of return to origin has changed.

Note 4) If workpiece retaining screws are too long, they can touch the guide block and cause a malfunction.

Use screws that are between the maximum and minimum screw-in depths in length.

Note 5) Secure the motor cable and lock cable so that the cables are not repeatedly bent.

Connector								
	Step motor	Servo motor						
Motor cable	20 20	24						
Lock cable	02 15	15 15						


Dimensions								[mm]
Model	L	С	D	E	F	G	Н	J
LES16R - 30 - 30 - 1	108.5	4	38	102.3	78	2	40	40
LES16R 50	136.5	6	34	130.3	106	2	78	78
LES16R75	180.5	8	36	174.3	150	4	36	72
LES16R 100	205.5	10	36	199.3	175	5	36	108






Dimensions: Basic Type/R Type

LES25R






With lock

- Note 1) Range within which the table can move when it returns to origin.

 Make sure a workpiece mounted on the table does not interfere with the workpieces and facilities around the table.
- Note 2) Position after return to origin.
- Note 3) [] for when the direction of return to origin has changed.
- Note 4) If workpiece retaining screws are too long, they can touch the guide block and cause a malfunction.


 Use screws that are between the maximum and minimum screw-in depths in length.
- Note 5) Secure the motor cable and lock cable so that the cables are not repeatedly bent.


Dimensions								[mm]
Model	L	С	D	E	F	G	Н	J
LES25R□□-30□-□□□□□	144.5	4	48	133.5	105	2	46	46
LES25R50	170.5	6	42	159.5	131	2	84	84
LES25R 75	204.5	6	55	193.5	165	2	112	112
LES25R 100	277.5	8	50	266.5	238	4	56	112
LES25R	302.5	8	55	291.5	263	4	59	118
LES25R - 150	327.5	8	62	316.5	288	4	62	124



Dimensions: Symmetrical Type/L Type

LES8L





Note 1) Range within which the table can move when it returns to origin.

Make sure a workpiece mounted on the table does not interfere with the workpieces and facilities around the table.

Note 2) Position after return to origin.

Note 3) [] for when the direction of return to origin has changed.

Note 4) If workpiece retaining screws are too long, they can touch the guide block and cause a malfunction.

Use screws that are between the maximum and minimum screw-in depths in length.

Note 5) Secure the motor cable and lock cable so that the cables are not repeatedly bent.

Connector							
	Step motor	Servo motor					
Motor cable	20	24					
Lock cable	15	02 15					

Motor cable (2 x ø5) Note 5)


Dimensions							[mm]
Model	L	D	E	F	G	Н	J
LES8L -30	94.5	26	88.7	62.5	2	27	27
LES8L -50 -50 -	137.5	46	131.7	105.5	3	29	58
LES8L -75	162.5	50	156.7	130.5	4	30	60





Dimensions: Symmetrical Type/L Type

LES16L



Note 1) Range within which the table can move when it returns to origin.

Make sure a workpiece mounted on the table does not interfere with the workpieces and facilities around the table.

(G - 1) x H

Note 2) Position after return to origin.

Note 3) [] for when the direction of return to origin has changed.

Note 4) If workpiece retaining screws are too long, they can touch the guide block and cause a malfunction.

Use screws that are between the maximum and minimum screw-in depths in length.


Note 5) Secure the motor cable and lock cable so that the cables are not repeatedly bent.


Connector								
	Step motor	Servo motor						
Motor cable	20	24						
Lock cable	15 15	07						

Dimensions								[mm]
Model	L	С	D	E	F	G	Н	J
LES16L -30	108.5	4	38	102.3	78	2	40	40
LES16L -50 -50 -	136.5	6	34	130.3	106	2	78	78
LES16L -75	180.5	8	36	174.3	150	4	36	72
LES16L -100	205.5	10	36	199.3	175	5	36	108

Dimensions: Symmetrical Type/L Type

LES25L





Note 2) Position after return to origin.


Note 3) [] for when the direction of return to origin has changed.

Note 4) If workpiece retaining screws are too long, they can touch the guide block and cause a malfunction.

Use screws that are between the maximum and minimum screw-in depths in length.

Note 5) Secure the motor cable and lock cable so that the cables are not repeatedly bent.


Dimensions								[mm]
Model	L	С	D	E	F	G	Н	J
LES25L□□-30□-□□□□□	144.5	4	48	133.5	105	2	46	46
LES25L -50	170.5	6	42	159.5	131	2	84	84
LES25L -75	204.5	6	55	193.5	165	2	112	112
LES25L - 100	277.5	8	50	266.5	238	4	56	112
LES25L -125	302.5	8	55	291.5	263	4	59	118
LES25L - 150	327.5	8	62	316.5	288	4	62	124







Dimensions: In-line Motor Type/D Type



- Note 1) Range within which the table can move when it returns to origin.

 Make sure a workpiece mounted on the table does not interfere with the workpieces and facilities around the table.

134

- Make sure a workpiece mounted on the table does not interfere with the workpieces and facilities around the table.

 Note 2) Position after return to origin.

 Note 3) [] for when the direction of return to origin has changed.

 Note 4) The distance between the motor end cover and the manual override screw is up to 16 mm. The motor end cover hole size is ø5.5.

 Note 5) The table is lower than the motor cover. Make sure it does not interfere with the workpiece.

 Note 6) If workpiece retaining screws are too long, they can touch the guide block and cause a malfunction.

 Use screws that are between the maximum and minimum screw-in depths in length.

 Note 7) Secure the motor cable and lock cable so that the cables are not repeatedly bent.

Dimensions


Dillicitatoria								[iiiiiii]
Model	(L)	В	D	E	F	G	J	K
LES8D	171.5	26	6	88.5	44.5	2	_	81
LES8D	225	26	٥	00.5	44.5	-	_	"
LES8D 50	214.5	46	6	131.5	64.5	4	23	124
LES8D	268		0	131.5	04.5			
LES8D75	239.5	50	6	156.5	64.5	4	48	149
LES8D	293		٥					


= 260


cable

15

Dimensions: In-line Motor Type/D Type







Note 1) Range within which the table can move when it returns to origin.

Make sure a workpiece mounted on the table does not interfere with the workpieces and facilities around the table.

Note 2) Position after return to origin.

Note 3 [] for when the direction of return to origin has changed.

Note 4) The distance between the motor end cover and the manual override screw is up to 17 mm. The motor end cover hole size is ø5.5.

Note 5) The table is lower than the motor cover. Make sure it does not interfere with the workpiece.

Note 6) If workpiece retaining screws are too long, they can touch the guide block and cause a malfunction. Use screws that are between the maximum and minimum screw-in depths in length.


Note 7) Secure the motor cable and lock cable so that the cables are not repeatedly bent.


Dimensions								[mm]
Model	(L)	В	D	E	F	G	J	K
LES16D -30	193	38	4	102.5	56.5	4	18.5	95.5
LES16D - 30B	256.5		4	102.5	56.5	4		95.5
LES16D -50 -50	221	34	6	130.5	65	4	38	123.5
LES16D 50B	284.5	34	0	130.5	65			
LES16D -75	265	36	8	174.5	84	4	63	167.5
LES16D -75B	328.5	1 30	۰	174.5	04	4	63	167.5
LES16D -100	290	36	10	100 5	0.4	6	44	100.5
LES16D - 100B	353.5		10	199.5	84			192.5





Dimensions: In-line Motor Type/D Type





Dimensione

Con	Connector						
	Step motor						
Motor cable	20						
Lock cable	02 15						

Note 1) Range within which the table can move when it returns to origin. Make sure a workpiece mounted on the table does not interfere with the workpieces and facilities around the table.

Note 2) Position after return to origin.

Note 3) [] for when the direction of return to origin has changed.

Note 4) The distance between the motor end cover and the manual override screw is up to 4 mm.
The motor end cover hole size is ø5.5.


Note 5) The table is lower than the motor cover.

Note 6) If workpiece retaining screws are too long, they can touch the guide block and cause a malfunction. Use screws that are between the maximum and minimum screw-in depths in length.

Note 7) Secure the motor cable and lock cable so that the cables are not repeatedly bent.

Dimensions								[mm]
Model	(L)	В	D	E	F	G	J	K
LES25D -30	214	48	4	133.5	81	4	19	121.5
LES25D□-30B□□-□□□□□	254.5	40	4	133.5	01	4	19	121.5
LES25D -50	240	42	6	159.5	87	4	39	147.5
LES25D - 50B	280.5			139.3	07	-	39	147.5
LES25D□-75□□-□□□□□	274	55	6	193.5	96	4	64	181.5
LES25D -75B	314.5	33				4		
LES25D - 100	347	50	8	266.5	144	4	89	254.5
LES25D - 100B	387.5	30	٥	200.5	144	4	09	
LES25D -125	372	55	8	291.5	144	6	57	279.5
LES25D□-125B□□-□□□□□	412.5	55	°	291.5	144	0	37	2/9.5
LES25D - 150	397	62	8	316.5	144	6	69.5	304.5
LES25D - 150B	437.5	02	8				09.5	304.5

Side Holder (In-line Motor Type/D Type)



							[mm]
Part no. Note)	Α	В	D	Е	F	G	Applicable model
LE-D-3-1	45	57.6	6.7	4.5	20	33	LES8D
LE-D-3-2	60	74	8.3	5.5	25	40	LES16D
LE-D-3-3	81	99	12	6.6	30	49	LES25D

Note) Model numbers for 1 side holder.

Electric Slide Table/High Rigidity Type **LESH** Series

Model Selection 1

LESH Series ▶Pages 350, 351-1



Selection Procedure For the compact type LES series, refer to page 314.



Step 1 Check the work load-speed.



Step 2 Check the cycle time.



Step 3 Check the allowable moment.

Selection Example-

Step 1 Check the work load-speed. <Speed-Work load graph> (Page 341) Select the target model based on the workpiece mass and speed with reference to the <Speed-Work load graph>.

> Selection example) The LESH16□J-50 is temporarily selected based on the graph shown on the right side.

Step 2 Check the cycle time.

It is possible to obtain an approximate cycle time by using method 1, but if a more detailed cycle time is required, use method 2.

* Although it is possible to make a suitable selection by using method 1, this calculation is based on a maximum load condition. Therefore, if a more detailed selection for each load is required, use method 2.

Method 1: Check the cycle time graph. (Page 342)

Method 2: Calculation <Speed-Work load graph> (Page 341)

Calculate the cycle time using the following calculation method.

Cycle time:

T can be found from the following equation.

. T1: Acceleration time and T3: Deceleration time can be obtained by the following equation.

$$T1 = V/a1 [s]$$

• T2: Constant speed time can be found from the following equation.

$$2 = \frac{L - 0.5 \cdot V \cdot (T1 + T3)}{V} [s]$$


• T4: Settling time varies depending on the conditions such as motor types, load and in position of the step data. Therefore, calculate the settling time with reference to the following value.

Operating conditions

- Workpiece mass: 1 [kg] Workpiece mounting condition: Speed: 220 [mm/s]
- Mounting orientation: Vertical
- •Stroke: 50 [mm]
- Acceleration/Deceleration: 5000 [mm/s²]
- Cycle time: 0.5 seconds



LESH16□/Step Motor Vertical



<Speed-Work load graph>

$T2 = \frac{L - 0.5 \cdot V \cdot (T1 + T3)}{V}$

T1 to T4 can be calculated as follows.

T1 = V/a1 = 220/5000 = 0.04 [s],

T3 = V/a2 = 220/5000 = 0.04 [s]

$$= 0.19 [s]$$

$$T4 = 0.15 [s]$$

Therefore, the cycle time can be obtained as follows.


$$T = T1 + T2 + T3 + T4$$

Calculation example)

$$= 0.04 + 0.19 + 0.04 + 0.15$$

$$= 0.42 [s]$$


LESH16□/Step Motor




<Cycle time>

Step 3 Check the allowable moment. <Static allowable moment> (Page 342) <Dvnamic allowable moment> (Pages 343, 344)

Confirm the moment that applies to the actuator is within the allowable range for both static and dynamic conditions.





<Dvnamic allowable moment>

Based on the above calculation result, the LESH16□J-50 is selected.





Speed-Work Load Graph (Guide)

Step Motor (Servo/24 VDC)

* The following graph shows the values when moving force is 100%.

LESH8□






Servo Motor (24 VDC)


* The following graph shows the values when moving force is 250%.


LESH8□A






LESH16□







LESH16□A







LESH25□






LESH25^RA







Cycle Time (Guide)



Operating Conditions

Acceleration/Deceleration: 5000 mm/s²

In position: 0.5 mm

Static Allowable Moment

Model		LES	SH8	LES	H16	L	ESH2	25
Stroke	[mm]	50	75	50	100	50	100	_
Pitching	[N·m]	1	1	26	43	77	112	155
Yawing	[N·m]	1	1	20	43	′′	112	155
Rolling	[N·m]	1	2	4	8	146	177	152



Dynamic Allowable Moment

* This graph shows the amount of allowable overhang (guide unit) when the center of gravity of the workpiece overhangs in one direction. When selecting the overhang, refer to "Calculation of Guide Load Factor" or the Electric Actuator Selection Software for confirmation, http://www.smcworld.com

Acceleration/Deceleration Load overhanging direction Model m : Work load [kg] Me: Dynamic allowable moment [N·m] LESH8 LESH16 LESH25 L : Overhang to the work load center of gravity [mm] [mm] [mm] Х Ξ Λ o 0.5 1.5 Work load m [kg] Work load m [kg] Work load m [kg] Horizontal/Bottom L2 [mm] mm Υ 0.5 o, Work load m [kg] Work load m [kg] Work load m [kg] L3 [mm] z ខ ទ Λ 0.5 Work load m [kg] Work load m [kg] Work load m [kg] L4 [mm] mm X 0.5 1.5 'n o, Work load m [kg] Work load m [kg] Work load m [kg] Horizontal (Wall) L5 [mm] E. O 0.5 Work load m [kg] Work load m [kg] Work load m [kg] **L6** [mm] **Fe** [mm] z 0.5 1.5

Work load m [kg]


Work load m [kg]

Work load m [kg]



Dynamic Allowable Moment

This graph shows the amount of allowable overhang (guide unit) when the center of gravity of the workpiece overhangs in one direction. When selecting the overhang, refer to "Calculation of Guide Load Factor" or the Electric Actuator Selection Software for confirmation, thttp://www.smcword.com



Calculation of Guide Load Factor

1. Decide operating conditions

Model: LESH

Size: 8/16/25

Mounting orientation: Horizontal/Bottom/Wall/Vertical

Acceleration [mm/s²]: **a** Work load [kg]: **m**

Work load center position [mm]: Xc/Yc/Zc

- 2. Select the target graph with reference to the model, size and mounting orientation.
- 3. Based on the acceleration and work load, obtain the overhang [mm]: Lx/Ly/Lz from the graph.
- 4. Calculate the load factor for each direction.

 α **x** = **Xc/Lx**, α **y** = **Yc/Ly**, α **z** = **Zc/Lz** 5. Confirm the total of α **x**, α **y** and α **z** is 1 or less.

 $\alpha x + \alpha y + \alpha z \le 1$

When 1 is exceeded, please consider a reduction of acceleration and work load, or a change of the work load center position and series.

2. Bottom 4. Vertical

--- Mounting orientation

Example

1. Operating conditions

Model: LESH

Size: 8


Mounting orientation: Horizontal

Acceleration [mm/s²]: 5000

Work load [kg]: 1.0

Work load center position [mm]: Xc = 80, Yc = 100, Zc = 60

2. Select three graphs from the top of the left side first row on page 343.



4. The load factor for each direction can be obtained as follows.


1. Horizontal


 $\alpha x = 80/480 = 0.17$


 α **y** = 100/225 = 0.44

 $\alpha z = 60/1200 = 0.05$

5. $\alpha x + \alpha y + \alpha z = 0.66 \le 1$









Electric Slide Table/High Rigidity Type

LESH Series

Model Selection 2

LESH Series ▶Pages 350, 351-1

Selection Procedure For the compact type LES series, refer to page 320.



Step 1 Check the required force.

Check the set value of pushing force.

Step 3 Check the duty ratio.

[ka]

Selection Example

Operating conditions

- Pushing force: 90 [N]
- · Mounting orientation: Vertical upward
- •Workpiece mass: 1 [kg] Speed: 100 [mm/s]
- Pushing time + Operation (A): 1.5 seconds
 - · All cycle time (B): 6 seconds
- Stroke: 100 [mm]



Step 1 Check the required force.

Calculate the approximate required force for pushing operation. Selection example) • Pushing force: 90 [N]

- Workpiece mass: 1 [kg]

Therefore, the approximate required force can be obtained as 90 + 10 = 100 [N].

Select the target model based on the approximate required force with reference to the specifications (Pages 352 and 353). Selection example) Based on the specifications,

- Approximate required force: 100 [N]
- Speed: 100 [mm/s]

Therefore, the **LESH25**□ is temporarily selected.

Then, calculate the required force for pushing operation. If the mounting position is vertical upward, add the actuator table weight.

Selection example) Based on the <Table weight>,

- LESH25□ table weight: 1.3 [kg]
- Therefore, the required force can be obtained as 100 + 13 = 113 [N].

Step 2 Check the set value of pushing force. <Set value of pushing force-Force graph> (Page 347)

Select the target model based on the required force with reference to the <Set value of pushing force-Force graph>, and confirm the set value of pushing force.

Selection example) Based on the graph shown on the right side.

• Required force: 113 [N]

Therefore, the LESH25□K is temporarily selected.

This set value of pushing force is 40 [%].

Step 3 Check the duty ratio.

Confirm the allowable duty ratio based on the set value of pushing force with reference to the <Allowable duty ratio>. Selection example) Based on the <Allowable duty ratio>,

> Set value of pushing force: 40 [%] Therefore, the allowable duty ratio can be obtained as 30 [%].

Calculate the duty ratio for operating conditions, and confirm it does not exceed the allowable duty ratio.

Selection example) • Pushing time + Operation (A): 1.5 seconds

· All cycle time (B): 6 seconds


Therefore, the duty ratio can be obtained as $1.5/6 \times 100 = 25$ [%], and this is the allowable range.

Based on the above calculation result, the LESH25□K-100 is selected. For allowable moment, the selection procedure is the same as the positioning control.

Table Weight

	,···			נפייו	
Model	Stroke [mm]				
Model	50	75	100	150	
LESH8	0.2	0.3	_	_	
LESH16	0.4	_	0.7	_	
LESH25	0.9	_	1.3	1.7	

* If the mounting position is vertical upward, add the table weight.



<Set value of pushing force-Force graph>

Allowable Duty Ratio


Step Motor (Servo/24 VDC)

Set value of pushing force (%)	Duty ratio (%)	Continuous pushing time (minute)	
30	_	_	
50 or less	30 or less	5 or less	
70 or less	20 or less	3 or less	

Servo Motor (24 VDC)

Set value of pushing force (%)	Duty ratio (%)	Continuous pushing time (minute)	
50	_	_	
75 or less	30 or less	5 or less	
100 or less	20 or less	3 or less	

* The pushing force of the LESH8 A is up to 75%.







Set Value of Pushing Force-Force Graph

Step Motor (Servo/24 VDC)


LESH8□



LESH16□




LESH25□




Servo Motor (24 VDC)

LESH8□A



LESH16□A



LESH25^RA









Table Accuracy





Model	LESH8	LESH16	LESH25
B side parallelism to A side [mm]	Refer to Table 1.		
B side traveling parallelism to A side [mm]	n] Refer to Graph 1.		
C side perpendicularity to A side [mm]	0.05	0.05	0.05
M dimension tolerance [mm]	±0.3		
W dimension tolerance [mm]	±0.2		
Radial clearance [µm]	-4 to 0	-10 to 0	-14 to 0

Table 1 B side parallelism to A side

Model		Stroke	Stroke [mm]			
Model	50	75	100	150		
LESH8	0.055	0.065	_	_		
LESH16	0.05	_	0.08	_		
LESH25	0.06	_	0.08	0.125		

Graph 1 B side traveling parallelism to A side





Traveling parallelism: The amount of deflection on a dial gauge when the table travels a full stroke with the body secured on a reference base surface




Table Deflection (Reference Value)

* These values are initial guideline values.

Table displacement due to pitch moment load Table displacement when loads are applied to the section marked with the arrow with the slide table stuck out.



Table displacement due to yaw moment load Table displacement when loads are applied to the section marked with the arrow with the slide table stuck out.



LESH8






Table displacement due to roll moment load Table displacement of section A when loads are applied to the section F with the slide table









Load [N]


LESH8 -75

LESH8□-50











LESH8

0.20

0.15


0.10

0.05


0.00


LESH₁₆

Table displacement [mm]



LESH25






Electric Slide Table/ High Rigidity Type

LESH Series LESH8, 16, 25

(**(c M** us RoHS)



Basic type (R type) Symmetrical type (L type) In-line motor type (D type)





4 Lead [mm]

Symbol	LESH8	LESH16	LESH25
J	8	10	16
K	4	5	8

6 Stroke [mm]

Stroke		None		
Stroke	Size	Applicable stroke		
50 to 75	8	50*2, 75		
50 to 100	16	50*2, 100		
50 to 150	25	50, 100, 150		


6 Motor option

Nil	Without option
В	With lock

Body option

Nil	Without option
S	Dust-protected*3

2 Motor mounting position



8 Mounting*4

•	•eug				
Symbol	Mounting	R type L type	D type		
Nil	Without side holder	•	•		
Н	With side holder (4 pcs.)	_	•		

H With side holder (4 pcs.) — •

3 Motor type


Symbol	Туре	Compatible controller/driver
Nil	Step motor (Servo/24 VDC)	LECP6 JXCE1 LECP1 JXC91 LECPA JXCP1 LECPMJ JXCD1 JXCL1
A	Servo motor*1 (24 VDC)	LECA6

9 Actuator cable type/length*6

Standard cable [m]		Robotic cable			[m]	
Nil	None	R1	1.5	RA	10*5	
S1	1.5*8	R3	3	RB	15* ⁵	
S3	3*8	R5	5	RC	20*5	
S5	5*8	R8	8*5			







Nil	Without controller/driver			
6N	LECP6/LECA6			
6P				
1N	LECP1*8	NPN		
1P	(Programless type)	PNP		
MJ	LECPMJ*8 *9 (CC-Link direct input type)			
AN	LECPA*8 *10	NPN		
AP	(Pulse input type)	PNP		

I/O cable length*11, Communication plug

Nil	Without cable (Without communication plug connector)*13
1	1.5 m
3	3 m*12
5	5 m*12
S	Straight type communication plug connector*13
Т	T-branch type communication plug connector*13




Controller/Driver mounting						
	Nil	Screw mounting				
	D	DIN rail mounting*14				

JXC Series (For details, refer to

Without controller





Communication plug connector for DeviceNet™*15

Nil	Without plug connector
S	Straight type
Т	T-branch type

- IO-Link *1 LESH25DA is not available.
- *2 R/L type with lock is not available.
- *3 For R/L type (IP5X equivalent), a scraper is mounted on the rod cover, and gaskets are mounted on both the end covers. For D type, a scraper is mounted on the rod cover.
- *4 Refer to page 365 for details.
- *5 Produced upon receipt of order (Robotic cable only)
- *6 The standard cable should only be used on fixed parts. For use on moving parts, select the robotic cable.
- *7 For details about controller/driver and compatible motor, refer to the compatible controller/driver on the next page.
- *8 Only available for the motor type "Step motor."
- *9 Not applicable to CE.

_Caution

[CE-compliant products]

1) EMC compliance was tested by combining the electric actuator LES series and the controller LEC/JXC series.

The EMC depends on the configuration of the customer's control panel and the relationship with other electrical equipment and wiring. Therefore, conformity to the EMC directive cannot be certified for SMC components incorporated into the customer's equipment under actual operating conditions. As a result, it is necessary for the customer to verify conformity to the EMC directive for the machinery and equipment as a whole

- 2 For the servo motor (24 VDC) specification, EMC compliance was tested by installing a noise filter set (LEC-NFA). Refer to page 568 for the noise filter set. Refer to the LECA series Operation Manual for installation.
- 3 CC-Link direct input type (LECPMJ) is not CE-compliant.

[UL-compliant products]

When conformity to UL is required, the electric actuator and controller/ driver should be used with a UL1310 Class 2 power supply.


- *10 When pulse signals are open collector, order the current limiting resistor (LEC-PA-R-\(\sigma\)) on page 596 separately.
- *11 When "Without controller/driver" is selected for controller/driver types, I/O cable cannot be selected. Refer to page 568 (For LECP6/LECA6), page 582 (For LECP1) or page 596 (For LECPA) if I/O cable is required.
- *12 When "Pulse input type" is selected for controller/driver types, pulse input usable only with differential. Only 1.5 m cables usable with open collector.
- *13 For the LECPMJ, only "Nil", "S" and "T" are selectable since I/O cable is not included
- *14 DIN rail is not included. Order it separately.
- *15 Select "Nil" for anything other than DeviceNet™.

The actuator and controller/driver are sold as a package.

Confirm that the combination of the controller/driver and the actuator is correct.

<Check the following before use.>

- 1) Check the actuator label for model number. This matches the controller/driver.
- 2 Check Parallel I/O configuration matches (NPN or PNP).



* Refer to the Operation Manual for using the products. Please download it via our website, https://www.smcworld.com





Compatible Controller/Driver

LEC□ Series Step data input type Step data input type **CC-Link direct** Programless type Pulse input type input type Type Series LECP6 LECA6 LECPMJ LECP1 LECPA Capable of setting up Value (Step data) input operation (step data) without Operation by pulse signals Features CC-Link direct input Standard controller using a PC or teaching box Step motor Servo motor Step motor Compatible motor (Servo/24 VDC) (24 VDC) (Servo/24 VDC) Maximum number of step data 64 points 14 points Power supply voltage 24 VDC Page 600 Reference page Page 560 Page 560 Page 576 Page 590

JXC□ Series								
Туре	EtherCAT® direct input type	EtherNet/IPTM direct input type	PROFINET direct input type	DeviceNet TM direct input type	IO-Link direct input type			
Series	JXCE1	JXC91	JXCP1	JXCD1	JXCL1			
Features	EtherCAT® direct input	EtherNet/IP™ direct input	PROFINET direct input	DeviceNet™ direct input	IO-Link direct input			
Compatible motor	Step motor (Servo/24 VDC)							
Maximum number of step data		64 points						
Power supply voltage		24 VDC						
Reference page		Page 603-5						



Specifications

Step Motor (Servo/24 VDC)

Model			LES	H8□	LESI	1 16□	LESH25□			
	Stroke [mm]		50,	75	50,	100	50, 100, 150			
	Work load [kg] Note 1) 3)	rizontal	2	1	8	5	12	8		
	Work load [kg] No. 1707	/ertical	0.5	0.25	2	1	4	2		
s	Pushing force [N] 30% to 70	70% Note 2) 3)	6 to 15	4 to 10	23.5 to 55	15 to 35	77 to 180	43 to 100		
<u>5</u>	Speed [mm/s] Note 1) 3)		10 to 200	20 to 400	10 to 200	20 to 400	10 to 150	20 to 400		
g	Pushing speed [mm/s]]	10 to 20	20	10 to 20	20	10 to 20	20		
pecifications	Max. acceleration/deceleration	ion [mm/s ²]			50	00				
ě	Positioning repeatabil	lity [mm]			±0.	.05				
s	Lost motion [mm] Note 4	4)			0.15 c	or less				
ctuator	Screw lead [mm]		4	8	5	10	8	16		
큥	Impact/Vibration resistance [[m/s ²] Note 5)			50/	/20				
Þ	Actuation type		Slide screw + Belt (R/L type), Slide screw (D type)							
	Guide type		Linear guide (Circulating type)							
	Operating temperature ra	ange [°C]	5 to 40							
	Operating humidity rang	ge [%RH]	90 or less (No condensation)							
ns	Motor size			20	□42					
읉	Motor type			Step motor (Servo/24 VDC)						
specifications	Encoder			Inci	remental A/B phase (800 pulse/rotation)					
e	Rated voltage [V]				24 VDC	C ±10%				
	Power consumption [V	W] Note 6)	2	0	4	3	6	7		
Electric	Standby power consumption when oper	erating [W] Note 7)	7	,	1	5	1	3		
쁣	Max. instantaneous power consump	ption [W] Note 8)	3	5	6	0	74			
t	Туре				Non-magn	etizing lock				
unit	Holding force [N]	Note 9)	24	2.5	300	48	500	77		
ock	Power consumption [W] ^N	Note 10) Note 9)	3.	3.5 2.9				5		
Page	Rated voltage [V]				24 VDC	C ±10%				

Note 1) Speed changes according to the work load. Check "Speed-Work Load Graph (Guide)" on page 341.

Note 2) Pushing force accuracy is ±20% (F.S.).

Note 3) The speed and force may change depending on the cable length, load and mounting conditions. Furthermore, if the cable length exceeds 5 m, then it will decrease by up to 10% for each 5 m. (At 15 m: Reduced by up to 20%)

Note 4) A reference value for correcting an error in reciprocal operation.

Note 5) Vibration resistance: No malfunction occurred in a test ranging between 45 to 2000 Hz. Test was performed in both an axial direction and a perpendicular direction to the lead screw. (Test was performed with the actuator in the initial state.) Impact resistance: No malfunction occurred when the actuator was tested with a drop tester in both an axial direction and a perpendicular direction to the lead screw. (Test was performed with the actuator in the initial state.)

Note 6) The power consumption (including the controller) is for when the actuator is operating.

Note 7) The standby power consumption when operating (including the controller) is for when the actuator is stopped in the set position during the operation. Except during the pushing operation.

Note 8) The maximum instantaneous power consumption (including the controller) is for when the actuator is operating. This value can be used for the selection of the power supply.

Note 9) With lock only

Note 10) For an actuator with lock, add the power consumption for the lock.

Specifications

Servo Motor (24 VDC)

Model		LESH8□A		LESH	16□A	LESH25 ^R A Note 1)				
	Stroke [mm]		50,	75	50,	100	50, 100, 150			
	Work load [kg]	Horizontal	2	1	5	2.5	6	4		
	work load [kg]	Vertical	0.5	0.25	2	1	2.5	1.5		
S	Pushing force 50	to 100% [N] Note 2)	7.5 to 11	5 to 7.5	17.5 to 35	10 to 20	31 to 62	19 to 38		
<u>5</u>	Speed [mm/s]		1 to 200	1 to 400	1 to 200	1 to 400	1 to 150	1 to 400		
cat	Pushing speed	[mm/s] Note 2)			1 to	20				
ŧ	Max. acceleration/de	eceleration [mm/s ²]			50	00				
ě	Positioning rep	eatability [mm]			±0.	.05				
Actuator specifications	Lost motion [m	m] Note 3)			0.15 c	or less				
atc	Screw lead [mm	1]	4	8	5	10	8	16		
턍	Impact/Vibration res	sistance [m/s²] Note 4)			50/	/20				
⋖	Actuation type		Slide screw + Belt (R/L type), Slide screw (D type)							
	Guide type		Linear guide (Circulating type)							
	Operating tempe	rature range [°C]								
	Operating humid	lity range [%RH]	90 or less (No condensation)							
ns.	Motor size			20		28		42		
을	Motor output [V	V]	1	10 30 36						
specifications	Motor type		Servo motor (24 VDC)							
ec:	Encoder			Incre	emental A/B (800 p	oulse/rotation)/Z pl	nase			
g	Rated voltage [24 VDC	C ±10%				
<u>1</u>	Power consum	ption [W] Note 5)	5	8	8	4	14	14		
Electric	Standby power consumption	n when operating [W] Note 6)	4 (Horizontal)/7 (Vertical)	2 (Horizontal)	/15 (Vertical)	4 (Horizontal)	/43 (Vertical)		
	Max. instantaneous powe	er consumption [W] Note 7)	8	4	12	24	15	58		
Lock unit ecifications	Туре					etizing lock				
catic	Holding force [f		24	2.5	300	48	500	77		
Silip	Power consumpti	ion [W] Note 9)	3.	5	2.	· ·	5			
ads	Rated voltage [V]			24 VDC	C ±10%				

- Note 1) LESH25DA is not available.
- Note 2) The pushing force values for LESH8 \square A is 50% to 75%. Pushing force accuracy is $\pm 20\%$ (F.S.).
- Note 3) A reference value for correcting an error in reciprocal operation.
- Note 4) Vibration resistance: No malfunction occurred in a test ranging between 45 to 2000 Hz. Test was performed in both an axial direction and a perpendicular direction to the lead screw. (Test was performed with the actuator in the initial state.)

 Impact resistance: No malfunction occurred when the actuator was tested with a drop tester in both an axial direction and a perpendicular direction to the lead screw. (Test was performed with the actuator in the initial state.)
- Note 5) The power consumption (including the controller) is for when the actuator is operating.
- Note 6) The standby power consumption when operating (including the controller) is for when the actuator is stopped in the set position during the operation. Except during the pushing operation.
- Note 7) The maximum instantaneous power consumption (including the controller) is for when the actuator is operating. This value can be used for the selection of the power supply.
- Note 8) With lock only
- Note 9) For an actuator with lock, add the power consumption for the lock.

Weight


Step Motor (Servo/24 VDC), Servo Motor (24 VDC) Common

Mode	Basic type/R type, Symmetrical type/L type						In-line motor type/D type								
lviode	LESH	18 ^R (A)	LESH	16 ^R (A)	LE	SH25 _L	(A)	LESH	8D(A)	LESH1	16D(A)	L	ESH25	D	
Stroke [mm]		50	75	50	100	50	100	150	50	75	50	100	50	100	150
Product	Without lock	0.55	0.70	1.15	1.60	2.50	3.30	4.26	0.57	0.70	1.25	1.70	2.52	3.27	3.60
weight [kg]	With lock	_	0.76	_	1.71	2.84	3.64	4.60	0.63	0.76	1.36	1.81	2.86	3.61	3.94

SMC



Construction: Basic Type/R Type, Symmetrical Type/L Type



Component Parts

Component Parts							
No.	Description	Material	Note				
1	Motor	_	_				
2	Body	Aluminum alloy	Anodized				
3	Table	Stainless steel	Heat treatment + Electroless nickel plating				
4	Guide block	Stainless steel	Heat treatment				
5	Lead screw	Stainless steel	Heat treatment + Specially treated				
6	End plate	Aluminum alloy	Anodized				
7	Pulley cover	Synthetic resin	_				
8	End cover	Synthetic resin	_				
9	Rod	Stainless steel	_				
10	Daning stance	Structural steel	Electroless nickel plating				
10	Bearing stopper	Brass	Electroless nickel plating (LESH25R/L only)				
11	Motor plate	Structural steel					
12	Lock nut	Structural steel	Chromate treated				
13	Socket	Structural steel	Electroless nickel plating				
14	Lead screw pulley	Aluminum alloy	_				
15	Motor pulley	Aluminum alloy	_				
16	Spacer	Stainless steel	LESH25R/L□ only				
17	Origin stopper	Structural steel	Electroless nickel plating				
18	Bearing	_	_				
19	Belt		_				
20	Grommet	Synthetic resin	_				
21	Sim ring	Structural steel	_				

No.	Description	Material	Note
22	Bushing	_	Dust-protected option only
23	Pulley gasket	NBR	Dust-protected option only
24	End gasket	NBR	Dust-protected option only
25	Scraper	NBR	Dust-protected option only/Rod
26	Cover	Synthetic resin	_
27	Return guide	Synthetic resin	_
28	Scraper	Stainless steel + NBR	Linear guide
29	Steel ball	Special steel	_
30	Lock	_	With lock only


Replacement Parts/Belt

Model	Order no.
LESH8□	LE-D-1-1
LESH16□	LE-D-1-2
LESH25□	LE-D-1-3
LESH25□A	LE-D-1-4

Replacement Parts/Grease Pack

Applied portion	Order no.
Guide unit	GR-S-010 (10 g) GR-S-020 (20 g)

Construction: In-line Motor Type/D Type



0

0

Component Parts



No.	Description	Material	Note
22	Steel ball	Special steel	_
23	Bearing	_	_
24	Sim ring	Structural steel	_
25	Masking tape	_	_
26	Scraper	NBR	Dust-protected option only/
20	Scraper	NDN	Rod
27	Lock	_	With lock only
28	Side holder	Aluminum alloy	Anodized

Optional Parts/Side Holder

Model	Order no.
LESH8D	LE-D-3-1
LESH16D	LE-D-3-2
LESH25D	LE-D-3-3

Replacement Parts/Grease Pack


Applied portion	Order no.
Guide unit	GR-S-010 (10 g) GR-S-020 (20 g)








Dimensions: Basic Type/R Type


LESH8R














Model	С	F	G	J	K	M	N
LESH8R 50	46	29	3	58	111	125.5	95.5
LESH8R75	50	30	4	60	137	151.5	121.5

Note 1) Range within which the table can move when it returns to origin. Make sure a workpiece mounted on the table does not interfere with the workpieces and facilities around the table.

Note 2) Position after return to origin.

Note 3 [] for when the direction of return to origin has changed.

Note 4) If workpiece retaining screws are too long, they can touch the guide block and cause a malfunction. Use screws that are between the maximum and minimum screw-in depths in length.


Note 5) Secure the motor cable and lock cable so that the cables are not repeatedly bent.




Dimensions: Basic Type/R Type

LESH16R (G - 1) x F Motor cable (2 x ø5) Note 5) depth G x ø10.5 ø5^{+0.03}_{+0.01} depth 5 A-A 85 G x M6 x 1 thread depth 12 8

D x M5 x 0.8 thread depth 6.5 Note 4)



(**D**/2 – 1) x **C**



	Connecto	or
	Step motor	Servo motor
Motor cable	20 20 20	24
Lock cable	2 15	15

Model	С	D	F	G	J	K	M	N
LESH16R	40	6	45	2	45	116.5	135.5	106
LESH16R	44	8	44	4	88	191.5	210.5	181

Note 1) Range within which the table can move when it returns to origin. Make sure a workpiece mounted on the table does not interfere with the workpieces and facilities around the table.

Note 2) Position after return to origin.

Note 3 [] for when the direction of return to origin has changed.


Note 4) If workpiece retaining screws are too long, they can touch the guide block and cause a malfunction.

Use screws that are between the maximum and minimum screw-in depths in length. Note 5) Secure the motor cable and lock cable so that the cables are not repeatedly bent.





Dimensions: Basic Type/R Type



Note 3 | 1 for when the direction of return to origin has changed.

Note 3) | 1 for when the direction of return to origin has changed.


Note 4) If workpiece retaining screws are too long, they can touch the guide block and cause a malfunction.


Use screws that are between the maximum and minimum screw-in depths in length.


Note 5) Secure the motor cable and lock cable so that the cables are not repeatedly bent.

Dimensions: Symmetrical Type/L Type

LESH8L







							[mm]
Model	С	F	G	J	K	M	N
LESH8L -50 -50	46	29	3	58	111	125.5	95.5
LESH8LDD-75DD-DDDDD	50	30	4	60	137	151.5	121.5

Note 1) Range within which the table can move when it returns to origin. Make sure a workpiece mounted on the table does not interfere with the workpieces and facilities around the table.

Note 2) Position after return to origin.

Note 3) [7] for when the direction of return to origin has changed.

Note 4) If workpiece retaining screws are too long, they can touch the guide block and cause a malfunction.

Use screws that are between the maximum and minimum screw-in depths in length.


Note 5) Secure the motor cable and lock cable so that the cables are not repeatedly bent.








Dimensions: Symmetrical Type/L Type


LESH16L














								[mm]
Model	С	D	F	G	J	K	M	N
LESH16L -50	40	6	45	2	45	116.5	135.5	106
LESH16L -100	44	8	44	4	88	191.5	210.5	181


Note 1) Range within which the table can move when it returns to origin. Make sure a workpiece mounted on the table does not interfere with the workpieces and facilities around the table.

Note 2) Position after return to origin.

Note 3) [7] for when the direction of return to origin has changed.

Note 4) If workpiece retaining screws are too long, they can touch the guide block and cause a malfunction.

Use screws that are between the maximum and minimum screw-in depths in length.











Dimensions: Symmetrical Type/L Type

LESH25L









								[mm]
Model	С	D	F	G	J	K	M	N
LESH25L -50 -50	75	4	80	2	80	143	168	132
LESH25L - 100	48	8	44	4	88	207	232	196
LESH25L - 150	65	8	66	4	132	285	310	274

Note 1) Range within which the table can move when it returns to origin. Make sure a workpiece mounted on the table does not interfere with the workpieces and facilities around the table.

Note 2) Position after return to origin.

Note 3) [] for when the direction of return to origin has changed.

Note 4) If workpiece retaining screws are too long, they can touch the guide block and cause a malfunction. Use screws that are between the maximum and minimum screw-in depths in length.


Note 5) Secure the motor cable and lock cable so that the cables are not repeatedly bent.






Dimensions: In-line Motor Type/D Type

LESH8D





	Connect	or
	Step motor	Servo motor
Motor cable	20	24
Lock cable	15 15	15

						[mm]
Model	L	В	E	F	J	K
LESH8D -50	201.5	46	111	54.5	19.5	110.5
LESH8D -50B	255	46				
LESH8D -75	227.5	F0	137	55.5	44.5	136.5
LESH8D -75B	281	50	137	55.5	44.5	136.5


- Note 1) Range within which the table can move when it returns to origin. Make sure a workpiece mounted on the table does not interfere with the workpieces and facilities around the table.
- on the table does not interfere with the workp Note 2) Position after return to origin.
- Note 3) [] for when the direction of return to origin has changed.
- Note 4) The distance between the motor end cover and the manual override screw is up to 16 mm.
 - The motor end cover hole size is ø5.5.
- Note 5) If workpiece retaining screws are too long, they can touch the guide block and cause a malfunction.


 Use screws that are between the maximum and minimum screw-in depths in length.
- Note 6) Secure the motor cable and lock cable so that the cables are not repeatedly bent.



Dimensions: In-line Motor Type/D Type

LESH16D





	Connector			
	Step motor	Servo motor		
Motor cable	20	24		
Lock cable	02 15	00 15		


							[mm]
Model	L	В	D	E	F	J	K
LESH16D -50	219.5	40	6	116.5	65	39.5	122
LESH16DDD-50BDD-DDDD	283	40	0	116.5	65	39.5	122
LESH16D -100	288.5	44	8	191.5	85	88.5	191
LESH16D -100B	352	44	l °	191.5	65	00.5	191

- Note 1) Range within which the table can move when it returns to origin. Make sure a workpiece mounted on
 - the table does not interfere with the workpieces and facilities around the table.
- Note 2) Position after return to origin.
- Note 3) [] for when the direction of return to origin has changed.
- Note 4) The distance between the motor end cover and the manual override screw is up to 17 mm.
 - The motor end cover hole size is ø5.5.
- Note 5) If workpiece retaining screws are too long, they can touch the guide block and cause a malfunction.

 Use screws that are between the maximum and minimum screw-in depths in length.
- Note 6) Secure the motor cable and lock cable so that the cables are not repeatedly bent.



Dimensions: In-line Motor Type/D Type



Note 1) Range within which the table can move when it returns to origin. Make sure a workpiece mounted on the table does not interfere with the workpieces and facilities around the table.

Note 2) Position after return to origin.

The motor end cover hole size is ø5.5.

Note 3 [] for when the direction of return to origin has changed.


Note 4) The distance between the motor end cover and the manual override screw is up to 4 mm.

Note 5) If workpiece retaining screws are too long, they can touch the guide block and cause a malfunction.

Use screws that are between the maximum and minimum screw-in depths in length.

Note 6) Secure the motor cable and lock cable so that the cables are not repeatedly bent.

Side Holder (In-line Motor Type/D Type)



							[mm]
Part no. Note)	Α	В	D	Е	F	G	Applicable model
LE-D-3-1	45	57.6	6.7	4.5	20	33	LESH8D
LE-D-3-2	60	74	8.3	5.5	25	40	LESH16D
LE-D-3-3	81	99	12	6.6	30	49	LESH25D

Note) Model numbers for 1 side holder.



LES/LESH Series Electric Slide Tables/ Specific Product Precautions 1

Be sure to read this before handling the products. Refer to back page 50 for Safety Instructions and pages 3 to 8 for Electric Actuator Precautions.

Design

∧ Caution

1. Do not apply a load in excess of the specification limits.

Select a suitable actuator by work load and allowable moment. If the product is used outside of the specification limits, the eccentric load applied to the guide will be excessive and have adverse effects such as creating play on the guide, degrading accuracy and shortening the life of the product.

Do not use the product in applications where excessive external force or impact force is applied to it.

This can cause failure.

Handling

↑ Caution

- 1. INP output signal
 - 1) Positioning operation

When the product comes within the set range by step data [In position], the INP output signal will turn on.

Initial value: Set to [0.50] or higher.

2) Pushing operation

When the effective force exceeds step data [Trigger LV], the INP output signal will turn on. Use the product within the specified range of [Pushing force] and [Trigger LV].

To ensure that the actuator pushes the workpiece with the set [Pushing force], it is recommended that the [Trigger LV] be set to the same value as the [Pushing force].

When the pushing operation is used, be sure to set to [Pushing operation]. Never hit at the stroke end except during return to origin.

When incorrect instructions are inputted, such as using the product outside of the specification limits or operation outside of actual stroke through changes in the controller/driver setting and/or origin position, the table may collide against the stroke end of the actuator. Check these points before use.

If the table collides against the stroke end of the actuator, the guide, belt or internal stopper can be broken. This may lead to abnormal operation.



Handle the actuator with care when it is used in the vertical direction as the workpiece will fall freely from its own weight.

- 3. Use the product with the following moving force.
 - Step motor (Servo/24 VDC): 100%
 - Servo motor (24 VDC) : 250%

If the moving force is set below the above values, it may cause an alarm.

Handling

∧ Caution

The actual speed of this actuator is affected by the load.

Check the model selection section of the catalog.

5. Do not apply a load, impact or resistance in addition to the transferred load during return to origin.

Additional force will cause the displacement of the origin position since it is based on detected motor torque.

- The table and guide block are made of special stainless steel, but can rust in an environment where droplets of water adhere to it.
- 7. Do not dent, scratch or cause other damage to the body, table and end plate mounting surfaces.

This may cause unevenness in the mounting surface, play in the guide or an increase in the sliding resistance.

8. Do not dent, scratch or cause other damage to the surface over which the rail and guide will move.

This may cause play or an increase in the sliding resistance.


9. Do not apply strong impact or an excessive moment while mounting a workpiece.


If an external force over the allowable moment is applied, it may cause play in the guide or an increase in the sliding resistance.

 Keep the flatness of mounting surface 0.02 mm or less.

Unevenness of a workpiece or base mounted on the body of the product may cause play on the guide and increased sliding resistance. Do not deform the mounting surface by mounting with workpieces tucked in.

- 11. Do not drive the main body with the table fixed.
- 12. When mounting the product, for R/L type fixed cable, keep the following dimension or more for bends in the cable. For D type, keep a 40 mm or longer diameter for bends in the cable.





Λ

LES/LESH Series Electric Slide Tables/ Specific Product Precautions 2

Be sure to read this before handling the products. Refer to back page 50 for Safety Instructions and pages 3 to 8 for Electric Actuator Precautions.

Handling

⚠ Caution

 When mounting the product, use screws with adequate length and tighten them to the maximum torque or less.

Tightening the screws with a higher torque than recommended may cause a malfunction, whilst the tightening with a lower torque can cause the displacement of the mounting position or in extreme conditions the actuator could become detached from its mounting position.

				01
Body fixed/	Model	Screw size	Max. tightening torque [N-m]	L (Max. screw-in depth [mm])
Side mounting	LES□8R/L	M4 x 0.7	1.5	8
(Body tapped)	LES□8D	M5 x 0.8	3	10
(Body tapped)	LES16R/L	IVIS X U.O	٥	10
—	LES16D			
	LESH16□	M6 x 1	5.2	12
	LES25R/L			
	LES25D	M8 x 1.25	10	16
	LESH25□	IVIO X 1.25	10	16

Body fixed/	Model	Screw size	Max. tightening torque (N-m)	L [mm]
Side mounting	LES8R/L	M3 x 0.5	0.63	23.5
(Through-hole)	LESH8R/L	IVIO X U.S	0.63	25.5
(Through-Hole)	LES□8D	M4 x 0.7	1.5	18.2
	LES16R/L	IVI-4 X U.7	1.5	33.5
	LES16D	M5 x 0.8	3	25.2
	LESH16R/L			35.5
	LESH16D			25.5
	LES25R/L			49
	LES25D			39.8
	LESH25R/L	M6 x 1	5.2	50.5
	LESH25D			39.5

Workpiece fixed/	Model	Screw size	Max. tightening torque (N-m)	L [mm]
Front mounting	LES8R/L	M3 x 0.5	0.63	6
	LESH8R/L	IVIS X U.S	0.63	5.5
ı - -	LES□8D	M4 x 0.7	1.5	
	LES16R/L	IVI4 X U.7	1.5	8
	LES16D	M5 x 0.8	3	
	LESH16□	WIS X 0.0	3	
	LES25R/L			12
\$1111111111111111111111111111111111111	LESH25R/L	M6 x 1	5.2	10
	LES□25D	1		14

To prevent the workpiece retaining screws from penetrating the end plate, use screws that are 0.5 mm or shorter than the maximum screw-in depth. If long screws are used, they can touch the end plate and cause a malfunction.

Workpiece fixed/ Top mounting						
		=				
•	°					

Model	Screw size	Max. tightening	L (Min. to Max.
iviouei	Screw Size	torque [N-m]	screw-in depth [mm])
LES8□	M3 x 0.5	0.63	2.1 to 4.1
LESH8□	IVI3 X U.5	0.63	5 (Max.)
LES16□	M4 x 0.7	1.5	2.7 to 5.7
LESH16□	M5 x 0.8	3	6.5 (Max.)
LES25□	NIO X U.8	3	3.3 to 7.3
LESH25	M6 x 1	5.2	8 (Max.)


To prevent the workpiece retaining screws from touching the guide block, use screws that are the maximum screw-in depth or less. If long screws are used, they can touch the guide block and cause a malfunction.

Body fixed/Side mounting (Side holder)



Model	Screw size	Max. tightening torque [N·m]	L [mm]
LES□8D	M4 x 0.7	1.5	6.7
LES□16D	M5 x 0.8	3	8.3
LES□25D	M6 x 1	5.2	12

When using the side holders to install the actuator, be sure to use the positioning pin. It can be displaced when vibration or excessive external force is applied.



14. In pushing operation, set the product to a position of at least 0.5 mm away from a workpiece. (This position is referred to as a pushing start position.)

If the product is set to the same position as a workpiece, the following alarms may be generated and operation may become unstable.

a. "Posn failed" alarm is generated.

The product cannot reach a pushing start position due to variation in the width of workpieces.

b. "Pushing ALM" alarm is generated.


The product is pushed back from a pushing start position after starting to push.

15. When external force is applied to the table, it is necessary to reduce the work load for the sizing.

When a cable duct or flexible moving tube is attached to the actuator, the sliding resistance of the table increases and may lead to operational failure of the product.

16. When using the side holders to install the actuator, use within the following dimension range.

Otherwise, installation balance will deteriorate and cause loosening.




Model	L [mm]
LES□8D□-30	5 to 10
LES□8D□-50	20 to 30
LES□8D□-75	50 to 60
LES□16D□-30	5 to 10
LES□16D□-50	20 to 30
LES□16D□-75	60 to 75
LES□16D□-100	85 to 100
LES□25D□-30	5 to 15
LES□25D□-50	25 to 35
LES□25D□-75	60 to 75
LES□25D□-100	70 to 100
LES□25D□-125	155 to 170
LES□25D□-150	160 to 180

17. For the LES□□D, do not grasp or peel off a masking tape on the bottom of the body.

The masking tape may peel off and foreign matter may get inside the actuator.

18. For the LES DD, a gap will form between the motor flange and table when the table moves (marked with the arrow below). Be careful not to put hands or fingers in a gap.



Λ

LES/LESH Series Electric Slide Tables/ Specific Product Precautions 3


Be sure to read this before handling the products. Refer to back page 50 for Safety Instructions and pages 3 to 8 for Electric Actuator Precautions.

Handling

∧ Caution


 When mounting the body with through-holes in the following mounting orientations, make sure to use two side holders as shown in the figures.

Otherwise, installation balance will deteriorate and cause loosening.



20. Install the body as shown below with the O.

Since the product support becomes unstable, it may cause a malfunction, noise or an increase in the deflection.




21. Even with the same product number, the table of some products can be moved by hand and the table of some products cannot be moved by hand. However, there is no abnormality with these products. (Without lock)

This difference is caused because there is a little variation with the positive efficiency (when the table is moved by the motor) and there is a large variation with the reverse-efficiency (when the table is moved manually) due to the product characteristics. There is hardly any difference among products when they are operated by the motor.

Handling

↑ Caution

22. For LES□□^R_L, remove the cap and operate the manual override screw with a hexagon wrench.



Maintenance

.Marning

- Ensure that the power supply is stopped before starting maintenance work or replacement of the product.
- 2. For lubrication, wear protective glasses.
- 3. Perform maintenance according to the following requirements.
 - Maintenance frequency

Perform maintenance according to the table below.

Frequency	Appearance check	Belt check
Inspection before daily operation	0	_
Inspection every 6 months*	_	0
Inspection every 250 km*	_	0
Inspection every 5 million cycles*	_	0

^{*} Select whichever comes first.

- · Items for visual appearance check
 - 1. Loose set screws, Abnormal dirt
 - 2. Check of flaw and cable joint
 - 3. Vibration, Noise

· Items for belt check (R/L type only)

Stop operation immediately and replace the belt when belt appear to be below.

a. Tooth shape canvas is worn out.

Canvas fiber becomes fuzzy. Rubber is removed and the fiber becomes whitish. Lines of fibers become unclear.

b. Peeling off or wearing of the side of the belt

Belt corner becomes round and frayed thread sticks out.

c. Belt partially cut

Belt is partially cut. Foreign matter caught in teeth other than cut part causes flaw.

d. Vertical line of belt teeth

Flaw which is made when the belt runs on the flange.

- e. Rubber back of the belt is softened and sticky.
- f. Crack on the back of the belt

